

EPack™ Controller User Guide

EPack™ Power management and control units
Versions 2.10 and later

HA031414 issue 3
September 2014



Restriction of Hazardous Substances (RoHS)

Product group

Epack

Table listing restricted substances


Chinese

限制使用材料一览表						
产品	有毒有害物质或元素					
Epack	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚
功率模块 16-32安培	X	X	O	O	O	O
功率模块 40-63安培	X	X	O	O	O	O
功率模块 80-100安培	X	X	O	O	O	O
功率模块 125安培	X	X	O	O	O	O
O	表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006 标准规定的限量要求以下。					
X	表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006 标准规定的限量要求。					

English

Restricted Materials Table						
Product	Toxic and hazardous substances and elements					
Epack	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Power Module 16-32A	X	X	O	O	O	O
Power Module 40-63A	X	X	O	O	O	O
Power Module 80-100A	X	X	O	O	O	O
Power Module 125A	X	X	O	O	O	O
O	Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006.					
X	Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363-2006.					

Approval

Name:	Position:	Signature:	Date:
Kevin Shaw	R&D Director		12/09/2014

EPack Power Controller

User Guide

List of sections

Section	Page
1 Introduction	3
2 Installation	3
3 Operator interface	14
4 Quickstart	17
5 Configuration from the front panel	23
6 Configuration using iTools	32
7 Using iTools	73
8 Parameter addresses	95
9 Alarms	96
10 Maintenance	99
A Technical specification	107
Index	i

Associated documents

HA028838 Printable version of iTools Help
HA025464 EMC installation guidelines

Software effectivity

This manual refers to instruments fitted with software version 2.10.

Epac Controller

User Guide

Contents List

Section	Page
SAFETY NOTES	1
SELV	2
SYMBOLS USED IN THE INSTRUMENT LABELLING	2
1 INTRODUCTION	3
1.1 UNPACKING THE UNITS	3
2 INSTALLATION	3
2.1 MECHANICAL INSTALLATION	3
2.1.1 Fixing details	3
BULKHEAD MOUNTING (32A AND 63A UNITS)	3
DIN RAIL MOUNTING FOR 32A AND 63A UNITS	4
BULKHEAD MOUNTING (80A, 100A AND 125A UNITS)	4
DIN RAIL MOUNTING FOR 80A, 100A AND 125A UNITS	4
2.2 ELECTRICAL INSTALLATION	9
2.2.1 EPack supply voltage	9
CONNECTION DETAILS	9
2.2.2 Load wiring	10
ENABLE INPUT	12
ALARM ACKNOWLEDGE	12
MAIN SETPOINT	12
RELAY OUTPUT	12
COMMUNICATIONS PINOUTS	13
3 OPERATOR INTERFACE	14
3.1 DISPLAY	14
3.1.1 Status area	14
3.1.2 Softkey icons	15
3.2 PUSHBUTTONS	15
3.2.1 Pushbutton functions	15
3.2.2 Menu item value selection	15
3.3 FRONT PANEL EVENT INDICATION	16
3.3.1 Instrument events	16
3.3.2 Indication alarms	16
3.3.3 System alarms	16
3.3.4 Process alarms	16
4 QUICKCODE	17
4.1 QUICKCODE MENU PARAMETERS	18
4.2 SOME DEFINITIONS	19
4.2.1 Firing modes	19
BURST VARIABLE FIRING	20
PHASE ANGLE CONTROL	20
HALF CYCLE MODE	20
4.2.2 Feedback type	21
4.2.3 Transfer Mode	21
4.2.4 Limitation features	22
FIRING ANGLE LIMITING	22
DUTY CYCLE LIMITING	22
CHOP OFF	22
5 CONFIGURATION FROM THE FRONT PANEL	23
5.1 MENU PAGES	23
5.1.1 Comms menu	24
5.1.2 Config menu	25
5.1.3 Meas menu	26
5.1.4 Strat menu	27
5.1.5 Alarm Relay menu	28
5.1.6 Info menu	29

List of Contents (Cont.)

Section	Page
5.1.7 Access menu	30
ACCESS TO MENUS	31
5.1.8 Alarms menu	31
6 CONFIGURATION USING ITOOLS	32
6.1 INTRODUCTION	32
6.2 OVERVIEW	32
6.3 ACCESS MENU	33
6.4 ALARM CONFIGURATION	34
6.5 COMMUNICATIONS CONFIGURATION	35
6.6 CONTROL CONFIGURATION	37
6.6.1 Control setup menu	38
PARAMETERS	38
6.6.2 Control Main menu	39
PARAMETERS	39
6.6.3 Control limit configuration	39
PARAMETERS	39
6.6.4 Control diagnostic menu	40
PARAMETERS	40
6.6.5 Control Alarm disable menu	40
PARAMETERS	40
6.6.6 Control Alarm detection parameters	41
PARAMETERS	41
6.6.7 Control Alarm signalling parameters	41
PARAMETERS	41
6.6.8 Control Alarm Latch parameters	42
PARAMETERS	42
6.6.9 Control Alarm Acknowledgement parameters	42
PARAMETERS	42
6.6.10 Control Alarm Stop parameters	43
PARAMETERS	43
6.7 ENERGY CONFIGURATION	44
PARAMETERS	44
6.7.1 Resolution	45
6.8 FAULT DETECTION MENU	46
PARAMETERS	46
6.9 FIRING OUTPUT MENU	48
6.9.1 Examples	49
6.10 INPUT/OUTPUT (IO) CONFIGURATION	50
6.10.1 Analogue input configuration	51
AI MAIN	51
ALMDIS	51
ALMDET	51
ALMSIG	52
ALMLAT	52
ALMACK	52
ALMSTOP	52
ALMRELAY	52
6.10.2 Digital input configuration	52
PARAMETERS	52
6.10.3 Relay status	53
PARAMETERS	53
6.11 INSTRUMENT CONFIGURATION MENU	54
6.11.1 Instrument display configuration	55
PARAMETERS	55
6.11.2 Instrument Config configuration	55
PARAMETERS	55
6.11.3 Instrument options configuration	56
PARAMETERS	56
6.11.4 Scaling Factor	56
SETPROV EXAMPLE	56

List of Contents (Cont.)

Section	Page
6.12 IP MONITOR CONFIGURATION	57
PARAMETERS	57
6.13 LGC2 (TWO INPUT LOGIC OPERATOR) MENU	58
6.13.1 Lgc2 Parameters	58
6.14 LGC8 (EIGHT-INPUT LOGIC OPERATOR) CONFIGURATION	60
6.14.1 Parameters	60
6.14.2 Inversion schematic	60
6.14.3 Invert input decoding table	61
6.15 MATH2 MENU	62
6.15.1 Math 2 Parameters	62
6.16 MODULATOR CONFIGURATION	64
6.16.1 Modulator parameters	64
6.17 NETWORK CONFIGURATION	65
6.17.1 Network Meas Menu	66
PARAMETERS	66
6.17.2 Network Setup configuration	67
PARAMETERS	67
6.17. Network alarms	69
ALMDIS	69
NETWORK ALMRELAY SUBMENU	69
6.18 QCODE	70
6.18.1 Parameters	70
6.19 SETPROV CONFIGURATION MENU	71
6.19.1 Setpoint provider parameters	71
6.20 USER VALUE CONFIGURATION MENU	72
6.20.1 User Value parameters	72
7 USING ITOOLS	73
7.1 iTools CONNECTION	73
7.1.1 Automatic detection	73
7.1.2 Ethernet (Modbus TCP) communications	73
7.1.3 Direct Connection	76
7.2 SCANNING FOR INSTRUMENTS	77
7.3 GRAPHICAL WIRING EDITOR	78
7.3.1 Toolbar	79
7.3.2 Wiring editor operating details	79
FUNCTION BLOCKS	80
WIRES	82
Wire Colours	83
COMPOUNDS	86
7.4 PARAMETER EXPLORER	88
Figure 7.4.1 Parameter explorer detail	89
7.4.2 Explorer tools	90
7.4.3 Context Menu	90
7.5 FIELDBUS GATEWAY	91
7.6 WATCH/RECIPE EDITOR	93
7.6.1 Creating a Watch List	93
ADDING PARAMETERS TO THE WATCH LIST	93
DATA SET CREATION	93
7.6.2 Watch Recipe toolbar icons	94
7.6.3 Watch/Recipe Context Menu	94
8 PARAMETER ADDRESSES (MODBUS)	95
8.1 INTRODUCTION	95
8.2 PARAMETER TYPES	95
8.3 PARAMETER SCALING	95
8.4 PARAMETER LIST	95

List of Contents (Cont.)

Section	Page
9 ALARMS	96
9.1 SYSTEM ALARMS	96
9.1.1 Missing mains	96
9.1.2 Thyristor short circuit	96
9.1.3 Thyristor open circuit	96
9.1.4 Over temperature	96
9.1.5 Network dips	96
9.1.6 Mains frequency fault	96
9.1.7 Chop Off alarm	96
9.2 PROCESS ALARMS	96
9.2.1 Total Load Failure (TLF)	96
9.2.2 Closed Loop alarm	96
9.2.3 Alarm input	96
9.2.4 Over current detection	97
9.2.5 OverVoltage Alarm	97
9.2.6 UnderVoltage Alarm	97
9.2.7 Partial Load Failure (PLF)	97
9.3 INDICATION ALARMS	98
9.3.1 Process Value Transfer active	98
9.3.2 Limitation active	98
9.3.3 Load Over-Current	98
10 MAINTENANCE	99
10.1 SAFETY	99
10.2 PREVENTIVE MAINTENANCE	99
10.3 FUSING	100
10.3.1 Fuse dimensions	101
10.4 INSTRUMENT UPGRADE	103
10.4.1 iTools upgrade	103
10.4.2 Firmware upgrade	103
10.4.3 Software upgrade	104
OBTAINING A PASSCODE VIA TELEPHONE	104
OBTAINING A PASSCODE VIA iTOOLS	104
Appendix A: TECHNICAL SPECIFICATION	107
A1 STANDARDS	107
A2 SPECIFICATION	107
INDEX	i

This page is deliberately left blank

SAFETY NOTES

WARNING

BRANCH-CIRCUIT PROTECTION AND SAFETY OVERLOAD PROTECTION

This product does not contain any branch-circuit protection or internal safety overload protection. It is the responsibility of the user to add branch-circuit protection upstream of the unit. It is also the responsibility of the user to provide external or remote safety overload protection to the end installation. Such branch-circuit and safety overload protection must comply with applicable local regulations.

UL: The abovementioned branch-circuit protection is necessary for compliance with National Electric Code (NEC) requirements.

WARNINGS

1. Any interruption of the protective conductor inside or outside the apparatus, or disconnection of the protective earth terminal is likely to make the apparatus dangerous under some fault conditions. Intentional interruption is prohibited.
 2. Before carrying out any wiring to the unit it must be ensured that all relevant power and control cables, leads or harnesses are isolated from voltage sources. Before carrying out any wiring to the unit it must be ensured that all relevant power and control cables, leads or harnesses are isolated from voltage sources. Wire conductor cross sections must comply with table 9 of IEC60947-1 (or NEC, Article 310 Table 310-16). (See [table 2.2.1](#) of this manual).
 3. This equipment is not suitable for isolation applications, within the meaning of EN60947-1.
 4. Under some circumstances, the power module heatsink temperature may rise above 50 degrees Celsius. If operators are likely to come into contact with such heatsinks, adequate warnings and barriers must be put in place in order to prevent injury.
 5. EPack alarms protect thyristors and loads against abnormal operation, and provide the user with valuable information regarding the type of fault. Under no circumstances should these alarms be regarded as a replacement for proper personnel protection. It is strongly recommended that the installing authority include independent, system-safety mechanisms to protect both personnel and equipment against injury or damage, and that such safety mechanisms be regularly inspected and maintained. Consult the EPack supplier for advice.
 6. For 24V supplies, in order to comply with safety requirements, the supply voltage must be derived from a SELV or PELV circuit.
-

Note:

The instrument shall have one of the following as a disconnecting device, fitted within easy reach of the operator, and labelled as the disconnecting device.

- a. A switch or circuit breaker which complies with the requirements of IEC947-1 and IEC947-3
 - b. A separable coupler which can be disconnected without the use of a tool.
-

1. Before any other connection is made, the protective earth terminal shall be connected to a protective conductor.
2. Whenever it is likely that protection has been impaired, the unit shall be made inoperative, and secured against accidental operation. The manufacturer's nearest service centre should be contacted for advice.
3. Any adjustment, maintenance and repair of the opened apparatus under voltage, is forbidden for safety reasons.
4. Units are designed to be installed in a cabinet connected to the protective earth according to IEC364 or applicable national standards. The cabinet must be closed under normal operating conditions. Adequate air conditioning/ filtering/ cooling equipment must be fitted to the cabinet in order to prevent the ingress of conductive pollution, the formation of condensation etc.

SAFETY NOTES (Cont.)








5. Units are designed to be mounted vertically. There must be no obstructions (above or below) which could reduce or hamper airflow. If more than one set of units is located in the same cabinet, they must be mounted in such a way that air from one unit is not drawn into another.
6. Signal and power voltage wiring must be kept separate from one another. Where this is impractical, shielded cables should be used for the signal wiring.
7. If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment might be impaired.
8. This product has been designed for environment A (Industrial). Use of this product in environment B (domestic, commercial and light industrial) may cause unwanted electromagnetic disturbances in which cases the user may be required to take adequate mitigation measures.

SELV

Safety Extra Low Voltage. This is defined (in EN60947-1) as an electrical circuit in which the voltage cannot exceed 'ELV' under normal conditions or under single fault conditions, including earth faults in other circuits. The definition of ELV is complex as it depends on environment, signal frequency etc. See IEC 61140 for further details.

SYMBOLS USED IN THE INSTRUMENT LABELLING

One or more of the symbols below may appear as a part of the instrument labelling

	Protective conductor terminal		Risk of electric shock
	AC supply only		Precautions against static electrical discharge must be taken when handling this unit
	Underwriters Laboratories listed mark for Canada and the US		Refer to the manual for instructions
	Do not touch Heatsink Hot Surface		

USER GUIDE

1 INTRODUCTION

This document describes the installation, operation and configuration of an EPack unit. The Unit includes the following analogue and digital inputs and outputs, fitted as standard:

Two digital inputs (contact closure or voltage level)

One analogue input

One change-over relay under software control, configurable by the user.

Also fitted are a pair of RJ45 Ethernet connectors for communications with a controlling pc or with other units.

Section two of this manual gives connector locations and pinouts.

The operator interface consists of a 1.5 inch square TFT display and four push buttons for navigation and data selection.

The unit comes in five versions with maximum load currents of: 32A, 63A, 80A, 100A and 125A.

The supply voltage for the units can be specified as either low voltage (24V ac/dc) or line voltage (85 to 550V ac). The choice is made at time of order and cannot be changed in the field.

1.1 UNPACKING THE UNITS

The units are despatched in a special pack, designed to give adequate protection during transit. If any of the outer boxes show signs of damage, they should be opened immediately, and the instrument examined. If there is evidence of damage, the instrument should not be operated and the local representative contacted for instructions.

After the instrument has been removed from its packing, the packing should be examined to ensure that all accessories and documentation have been removed. The packing should then be stored against future transport requirements.

2 INSTALLATION

2.1 MECHANICAL INSTALLATION

2.1.1 Fixing details

The units are designed to operate at an operating temperature not exceeding 45°C at an altitude not exceeding 1000 metres. Units must be installed in a fan-cooled cabinet (with fan failure detection or thermal safety cutout). Condensation and conductive pollution should be excluded to IEC 664 class 2. The cabinet must be closed and connected to the protective earth according to IEC 60634 or applicable national standard.


Units must be mounted with the heat sink vertical with no obstructions above or below which impede the airflow. Where more than one set of modules is enclosed in the same cabinet, they must be mounted such that air from one unit is not drawn in by another mounted above it. A minimum gap of 10mm is required between units.

Figures 2.1.1b to 2.2.1e show dimensions for the various units.

The units are designed for Din Rail or bulkhead mounting using the fixings supplied.

BULKHEAD MOUNTING (32A AND 63A UNITS)

For Bulkhead mounting, fit the upper bracket 'A' to the rear of the unit by removing screw 'B' and associated shakeproof washer, offering the bracket up to the unit, and then securing it using screw 'B' ensuring that the bracket is correctly oriented (as shown) and that the shakeproof washer is fitted between the screw head and the bracket. The relevant screwdriver should have a 3mm AF hexagonal bit. The recommended tightening torque is 1.5Nm (1.1 lb-ft).



Note: 32A unit shown; 63A units similar.

2.1.1 MECHANICAL INSTALLATION (Cont.)


DIN RAIL MOUNTING FOR 32A AND 63A UNITS

The 32A and 63A units can be mounted using a standard 7.5 mm or 15 mm DIN rail, mounted horizontally.

BULKHEAD MOUNTING (80A, 100A AND 125A UNITS)

For Bulkhead mounting, fit the upper bracket 'A' to the rear of the unit by removing screws 'B' and associated shakeproof washers, offering the bracket up to the unit, and then securing it using screws 'B' ensuring that the bracket is correctly oriented (as shown) and that the shakeproof washers are fitted between the screw heads and the bracket. The relevant screwdriver should have a 3mm AF hexagonal bit. The recommended tightening torque is 1.5Nm (1.1 lb-ft).

Note: 80/100A unit shown; 125A units similar.



DIN RAIL MOUNTING FOR 80A, 100A AND 125A UNITS

These higher power units can be mounted, using two horizontal, parallel, 7.5 mm or 15 mm DIN rails, as shown below.




Figure 2.1.1a DIN rail mounting details for 80A, 100A and 125A units

2.1.1 MECHANICAL INSTALLATION (Cont.)




Figure 2.1.1b mechanical installation details (16A to 32A units).

2.1.1 MECHANICAL INSTALLATION (Cont.)




Figure 2.1.1c mechanical installation details (40A to 63A units).

2.1.1 MECHANICAL INSTALLATION (Cont.)




Figure 2.1.1d Mechanical installation details (80A to 100A units) (doors open).

2.1.1 MECHANICAL INSTALLATION (Cont.)




Figure 2.1.1e Mechanical installation details (125A units) (Doors open).

2.2 ELECTRICAL INSTALLATION

CAUTION

It must be ensured that an effective strain relief mechanism (e.g. trunking) is in place for all EPack cables. Failure to ensure this may result in the unintentional disconnection of one of more connectors resulting in unexpected and possibly dangerous lack of control.

2.2.1 EPack supply voltage

The supply voltage connections (to operate the Epack unit) are terminated using a 2-way (24V ac/dc version) or 3-way (85 to 550Vac version) connector, located on the upper side of the unit, as shown in figures 2.2.2a and 2.2.2b, below.

The supply voltage 85Vac to 550Vac shall be protected by ATM2 rated 600Vac/dc, 2A by MERSEN/Ferraz Shawmut (E33925)

In order to protect the wiring it is recommended that a branch circuit fuse be incorporated. (1Amp for 24Vac/dc supplies and 2 Amp for 85 to 550Vac supplies)

A safety earth connection must be made to the unit with a Listed ring type crimp terminal, using the nut and shakeproof washer supplied (M5 for 32A and 63A units; M6 for 100A and 125A units).

CONNECTION DETAILS

WARNING

For 24V supplies, in order to comply with safety requirements, the supply voltage must be derived from a SELV or PELV circuit.

Table 2.2.1 below, gives details of wire sizes and tightening torques for the various supply power and signal wiring connections. Wire conductor cross sections must comply with table 9 of IEC60947-1 (or NEC, Article 310 Table 310-16)

Where a range of wire sizes is given it is up to the user to select the correct cross sectional area required for the application. The safety earth cable should be, as a minimum, of the same cross sectional area as the cables used for the load (i.e. the cables terminated at the 1/L1 and 2/T1 terminals).

Connector	EPack version	Wire gauge and temperature rating	Tightening torque	Comments
Supply voltage (1/L1) and Load supply (2/T1)	32 Amp	2.5 to 6 mm ² (12 to 10 AWG) Rated 90 °C	1.7 Nm (15 lb. inch)	Flat-bladed screwdriver 0.6 or 0.8 x 4.5 mm
	63 Amp	10 to 16 mm ² (8 to 6 AWG) Rated 90 °C	1.7 Nm (15 lb. inch)	Flat-bladed screwdriver 0.6 or 0.8 x 4.5 mm
	80 Amp 100 Amp	25 to 35 mm ² (4 to 1 AWG) Rated 90 °C	5.6 Nm (50 lb. inch)	Flat-bladed screwdriver 1 x 5.5 mm or 1.2 x 6.5 mm
	125 Amp	50 mm ² (1/0 to 2/0 AWG) Rated 90 °C	5.6 Nm (50 lb. inch)	Flat-bladed screwdriver 1 x 5.5 mm or 1.2 x 6.5 mm
Safety earth	32 Amp 63 Amp	Same as respective Supply (1/L1) and Load (2/T1) cables	2.5 Nm (22 lb. inch)	Listed ring-type crimp terminal must be used
	80, 100 and 125A	Same as respective Supply (1/L1) and Load (2/T1) cables	5.6 Nm (50 lb. inch)	Listed ring-type crimp terminal must be used
Phase reference (N/L2) (2-way) EPack supply (24V ac/dc) (2-way) EPack supply (85V to 550V ac) (3-way) I/O connector (5-way) Relay connector (3-way)	All	0.25 to 2.5 mm ² (24 to 12 AWG) Rated 75 °C	0.56 Nm (5 lb. inch)	Flat-bladed screwdriver 0.6 x 3.5mm

Table 2.2.1 Cable cross-sections and tightening torques

2.2.2 Load wiring

The supply voltage for the load is connected at a terminal located on the upper side of the unit. The load is connected at the terminal located on the lower side of the unit. Figure 2.2.2a shows the 32 Amp unit (63 Amp unit similar) and figure 2.2.2b gives similar information for the 80/100 Amp unit (125Amp units similar).





Figure 2.2.2a Supply power connection details (32A and 63A units)

2.2.2 LOAD WIRING (Cont.)




Figure 2.2.2b Supply power connection details (80/100A units)

Note: See figure 2.2.2a for basic wiring details

IP20 WARNINGS

1. In order to maintain IP20 protection, the stripped length of the power cables (1/L1 and 2/T1) must be adapted according to the insulation thickness.
2. If the upper and/or lower access door is open, the product protection is IP10.
3. If the N/L2 connector is removed, IP20 rating is not guaranteed.
4. Breakaway features have been designed into the product especially to improve the IP20 rating. These features should be removed only for cable cross sections of 50mm² or more.

2.2.3 Signal wiring

Figure 2.2.3 shows the connector location, on the underside of the unit, for the digital and analogue inputs, and for the internal relay output.

ENABLE INPUT

In order for the power module thyristors to operate, the Enable input must be valid. In the default configuration, this is achieved by shorting pins 0V and DI1 of the I/O connector located on the underside of the unit (Digital input 1), or by using a User Value block to apply a logic high to the enable input to the relevant firing block in iTools.

If required, DI1 can be configured as a voltage input, and in this case it requires a high signal to be applied to DI1 with the relevant zero voltage connected to 0V.

ALARM ACKNOWLEDGE

In the default configuration, shorting pins 0V and DI2 of the I/O connector located on the underside of the unit (Digital input 2) acknowledges alarms. As an alternative, a logic input can be wired to the relevant parameter using iTools.

DI2 can be configured as a voltage input (if required), and in this case it requires a high signal to be applied to DI2 with the relevant zero voltage connected to 0V.

MAIN SETPOINT

In the default configuration, the analogue input sets the main setpoint.

RELAY OUTPUT

The relay is normally energised (common and normally open shorted), and is de-energised (common and normally closed shorted) when active. In the default configuration, the relay output is operated by the Fault detect 'Custom Alarm' ([section 6.8](#)) becoming active. By default, the Custom alarm is set up to be equivalent to 'AnySystemAlarm' which becomes active if any 'stop firing' error, such as those listed below, is detected.

If the Graphical Wiring Editor is available, iTools can be used to reconfigure the relay such that it operates under the control of any suitable parameter. (iTools must be in Configuration mode.)

In configuration mode, it is also possible to configure the relay using the 'AlmRly' tab in any function block (e.g. analogue input ([section 6.10.1](#))) which includes alarm functions, or from the Alarm Relay menu in the Operator Interface ([section 5.1.5](#)).

1. Missing mains. Supply voltage line is missing.
2. Thyristor short circuit*
3. Network dips. A reduction in supply voltage exceeding a configurable value (VdipsThreshold), causes firing to be inhibited until the supply voltage returns to a suitable value. VdipsThreshold represents a percentage change in supply voltage between successive half cycles, and can be defined by the user in the Network.Setup menu, as described in [section 6.17.2](#)
4. Freq Fault. The supply frequency is checked every half cycle, and if the percentage change between successive 1/2 cycles exceeds a threshold value (max. 5%), a Mains Frequency System Alarm is generated. The threshold value (FreqDriftThold) is defined in the Network.Setup menu described in [section 6.17.2](#)
5. Supply failure to Epack unit.
6. Chop Off ([section 4.2.4](#))
7. Analogue input over current. For mA inputs this alarm is active if there is too high a current flowing through the shunt.
8. Line under voltage (configurable between 2 and 30% of nominal voltage) ([section 6.17.2](#)).
9. Line over voltage (configurable between 2 and 10% of nominal voltage) ([section 6.17.2](#)).
10. Over current (configurable between 10 and 400% of nominal current) ([section 6.17.2](#)).

* Note... It is not possible to detect a thyristor short circuit when the unit is delivering 100% output power.

The relay is de-energised temporarily then re-energised at start-up.

2.2.3 SIGNAL WIRING (Cont.)




Figure 2.2.3 I/O details

Notes:

1. DI1 shown; DI2 similar
2. DI1 and DI2 can both be contact inputs or both be voltage inputs or be one of each.
3. Analogue input type (Volts or mA) is selected in I/O Analogue IP configuration (section 6.10.1). When a mA range is selected, a suitable shunt resistor is automatically connected into circuit. It is thus unnecessary for the user to fit external components.


COMMUNICATIONS PINOUTS

A pair of RJ45 connectors, wired in parallel is located on the front of the unit. Each connector has a pair of LED indicators to indicate network connection (amber LED) and network Tx activity (flashing green).

The connection is 10/100 base T, autosensing.

Pin	Signal
8	Not used
7	Not used
6	Rx-
5	Not used
4	Not used
3	Rx+
2	Tx-
1	Tx+

LEDs:
Green = Tx activity
Yellow = Connected



3 OPERATOR INTERFACE

Located at the front of the Driver Module, the operator interface consists of a 26mm square display, and, four push-button switches.

3.1 DISPLAY

The display is divided vertically into three areas, which for the purposes of this manual are called the status area at the top, the data display, in the centre, and the softkeys at the bottom. This display, together with the four pushbuttons allows full operation and configuration of the unit.




Figure 3 Operator interface

The figure above shows a typical operator mode screen set, scrolled through using the return (page) push-button. The configuration of the unit defines which parameters actually appear.




Notes:

1. The Energy display appears only if the Energy option is fitted
2. The Alarms display appears only if there are any active alarms. The up/down arrow pushbuttons can be used to scroll through the alarm list, if there are more alarms active than can be displayed on one screen height.

The 'Goto' item allows the user to enter Engineer or Configuration mode, providing the password(s) are known. [Section 5.1.5](#) describes the procedure (although the screen displays are different because in that section, the unit is shown in configuration mode).

3.1.1 Status area

This area at the top of the screen contains text descriptive of the current operation, and a number of icons as follows:

-  Configuration key. Displayed when the unit is in configuration mode.
-  Ethernet connection key. If upper connector on the front panel has an active ethernet connection, then the upper of the two green dots is illuminated. If the lower connector has an active ethernet connection, then the lower spot is illuminated.
-  Alarm symbol. Indicates that one of more alarms is active.

3.1.2 Softkey icons

A number of icons can appear at the bottom of the display, and each icon represents the action of the pushbutton immediately below it.



Menu. This appears in the bottom left corner, and operation of the Return pushbutton causes the top level menu to appear.



Return. This red cross icon appears in the bottom left corner, and operation of the Return pushbutton causes any configuration changes on the current page to be 'undone' or, if none, causes the display to 'go up' one level.



Plus and minus icons. Operation of the associated scroll up/down pushbutton causes the displayed value to increment or decrement.



Up/down arrows. Operation of the associated scroll up/down pushbutton causes the various menu items on display to be scrolled through.



Right/Left arrow. The right-pointing arrow appears in the bottom right-hand corner, and operation of the Enter pushbutton causes the cursor to shift right. Once this has been done, a left-pointing arrow appears in the bottom left-hand corner, allowing the user to shift the cursor to the left using the Return pushbutton.




Enter. This green tick appears in the bottom right corner, and operation of the Enter pushbutton causes any configuration change(s) on the display page to be confirmed.



Remote/Local. This appears in the bottom right corner, and operation of the Enter pushbutton toggles the setpoint selection between local and remote.

3.2 PUSHBUTTONS

The functions of the four pushbuttons below the display depend on what is displayed in the softkey area. The leftmost pushbutton (Return) is associated with the leftmost softkey, the down arrow pushbutton is associated with the next softkey and so on. In the example above, the 'Return' key is used both to enter the Menu, and to return from it to the initial display.



3.2.1 Pushbutton functions

Return	Returns to previous menu (while menus are displayed), cancels editing (during parameter editing), and performs screen cycling (during operator mode).
Scroll down/up	Allows the user to scroll through the available menu items or values.
Enter	Goes to next menu item. In parameter edit mode, this button confirms the changes.

3.2.2 Menu item value selection

Menu items are scrolled through using the up/down pushbuttons. Once the required item is displayed, the Enter pushbutton is used to select it for editing. Editing of the item's value is carried out by scrolling through the available choices, using the up and down scroll keys. Once the desired value is displayed, the Enter pushbutton is used to confirm the choice.

Where multiple changes have to be made (as in editing an IP address for example), the Enter pushbutton acts as a right cursor key, moving from the field just edited to the next field. (The Return key moves the cursor left). Once all fields have been edited, the enter key is used a final time to confirm the choice.

3.3 FRONT PANEL EVENT INDICATION

A number of instrument alarms and events can occur, and these are indicated by icons appearing on the display screen. The events and alarms are listed below. See [section 9](#) for a more details.

3.3.1 Instrument events

Conf Entry	The instrument has been placed in configuration mode (cogwheel symbol).
Conf Exit	The instrument has been taken out of configuration mode (no icon).
GlobalAck	A global acknowledgement of all safe latched alarms has been performed.
Quick Code Entry	The Quick Code menu is active (cogwheel icon + 'QCode' in display area).

The following alarms all cause a red bell icon to appear in the top right hand corner of the screen.

3.3.2 Indication alarms

LimitAct	One or more limits are active in the control block
LoadOverl	An over current alarm has become active in one or more Network blocks.
PrcValTfr	Process value transfer is active in the control block.

3.3.3 System alarms

ChopOff	The 'Chop-off' alarm has been detected.
FuseBlown	There is no internal fuse, but it is possible to use DI2 as a 'fuse-blown' input wired to the alarm block in iTools.
MainsFreq	Mains Frequency is outside the acceptable range.
Missmains	Supply power is missing.
NetwDip	The 'network dip' alarm has been detected.
Thyr SC	Thyristor short circuit. It is not possible to detect a thyristor short circuit when the unit is delivering 100% output power.

3.3.4 Process alarms

ClosedLp	The Control block 'Closed Loop' alarm has been detected.
Ana_In Over C	Over current in shunt. If this alarm is detected, firing is stopped by default.
Under Volt	Line under voltage (configurable between 2 and 35% of nominal voltage).
Over Volt	Line over voltage (configurable between 2 and 10% of nominal voltage)
PLF	The 'Partial Load Failure' alarm has been detected.
TLF	The 'Total Load failure' alarm has been detected.

4 QUICKCODE

At first switch-on, the Driver Module enters the 'QuickCode' menu which allows the user to configure the major parameters without having to enter the full configuration menu structure of the unit. Figure 4 shows an overview of a typical QuickCode menu. The actual displayed menu items will vary according to the number of software features purchased. When 'Finish' is selected to 'Yes', the instrument cold starts after confirmation (Enter key); when set to 'Cancel' the instrument discards any changes and restarts with the previous configuration.




Figure 4a Typical QuickCode menu

Notes:

1. If the unit has been fully configured at the factory, the Quickcode menu will be skipped, and the unit will go into operation mode at first switch on.
2. Once quit, the Quickcode menu can be returned to at any time from the Access menu (described later in this document (section 6)). Returning to the Quickcode menu cold-starts the unit.

4 QUICKCODE MENU (Cont.)




Figure 4b iTools Qcode page

4.1 QUICKCODE MENU PARAMETERS

Language	Select English, French, German, Italian or Spanish. Once confirmed all further displays appear in the selected language.
V Nominal	The nominal value of the supply voltage (valid entries are 20V to 500V). Default value appears. Use the up/down arrow buttons to edit.
I Nominal	The current flowing through the load according to the nominal load power. This current must not exceed the maximum current the unit can safely sustain. Lower values are not recommended as in such cases, the resulting accuracy and linearity are not guaranteed to be within specification. Default value appears. Use up/down arrow buttons to edit.
Firing Mode	Select from IHC (Half Cycle), Burst Var (Burst Variable), Burst Fix (Burst Fixed), Logic or Phase Angle.
Control	Select VSq (V^2), Isq (I^2) or Power
ILimit	Used to enable/disable threshold limit.
I ² Transfer	This is used to enable/disable the transfer feature. Quick code configures squared current as the transfer process value.
XFRMR (Transfo.)	No = Resistive load type; Yes = Transformer primary.
Heater	Select from Resistive, (Short wave) Infra red, CSi (Silicon carbide) or MOSi2 (Molybdenum disilicide)
AnaIn Functi	Select SP (setpoint), HR (setpoint limit), CL (current limit), TS (transfer limit) or None (no function) as Analogue Input function
AnaIn Type	Select 0 to 10V, 1 to 5V, 2 to 10V, 0 to 5V, 0 to 20mA or 4 to 20 mA as analogue input type.
DI1 Fct	Select 'Firing Enable' or 'None'.
DI2 Fct	Alarm ack(nowledge), RemSP sel (select remote setpoint), Fuse Blown, or none.
Link Speed	Select from 'AutoNego', 100Mb, 100 Mb Half duplex, 10 Mb, 10Mb Half duplex.
IP Mode	Choose 'Fixed' or 'DHCP'
IP Address	For fixed mode, allows the IP address to be edited, one section at a time. Use the up-down arrow pushbuttons to edit the first section (XXX.xxx.xxx.xxx), then 'Enter' to move to the next section (xxx.XXX.xxx.xxx) and repeat until all four sections are as required
SubNetMask	As for IP address above, but for the subnet mask.
Finish	If 'Yes' is selected (and confirmed using the enter key), quick code exits and the instrument restarts with the new configuration. If 'No' is selected then no action is taken and the user can continue to edit the quick code parameters. If 'cancel' is selected then all changes are discarded, quick code exits and the instrument restarts with the previous (i.e. unedited) configuration.

4.2 SOME DEFINITIONS

4.2.1 Firing modes

LOGIC

Power switches on, two or three zero crossings of the supply voltage after the logic input switches on. Power switches off two zero crossings of current after the logic input switches off. For resistive loads, voltage and current cross zero simultaneously. With inductive loads, a phase difference exists between the voltage and current, meaning that they cross zero at different times. The size of the phase difference increases with increasing inductance.

Power on-off delay = two or three mains periods depending on where in the mains cycle the logic output changes state.




Figure 4.2.1a Logic firing mode

BURST FIXED FIRING

This means that there is a fixed 'cycle time' equal to an integer number of supply voltage cycles as set up in the Modulator menu. Power is controlled by varying the ratio between the on period and the off period within this cycle time (figure 4.2.1b).




Figure 4.2.1b Burst Fixed mode

4.2.1 FIRING MODES (Cont.)

33% DUTY CYCLE

For duty cycles less than 50%, the firing time is one half-cycle. For a 33% duty cycle, firing time is one half cycle; the non-firing time is two half-cycles (figure 4.2.1f).




Figure 4.2.1f Half cycle mode: 33% duty cycle

66% DUTY CYCLE

For duty cycles of greater than 50%, the non-firing time is one half-cycle. For 66% duty cycle, the firing time is two half cycles; the non-firing time is one half cycle (figure 4.2.1g).




Figure 4.2.1g Half cycle mode: 66% duty cycle

4.2.2 Feedback type

All feedback types (except 'Open Loop') are based on real-time measurement of electrical parameters that are normalised to their equivalent Nominal values.

V^2	Feedback is directly proportional to the square of the RMS voltage measured across the load. For two- or three-phase systems, feedback is proportional to the average of the squares of the individual phase-to-phase or phase-to-Neutral RMS voltage across each load.
Power	Feedback is directly proportional to the total true power delivered to the load network.
I^2	Feedback is directly proportional to the square of the RMS current through the load. For two- or three-phase systems, feedback is proportional to the average of the squares of the individual RMS load currents.
Open loop	No measurement feedback. The thyristor firing angle in Phase angle mode, or the duty cycle in burst-firing mode, are proportional to the setpoint.

4.2.3 Transfer Mode

The control system can use automatic transfer of certain feedback parameters. For example with loads with very low cold resistance, I^2 feedback should be used to limit inrush current, but once the load has started to warm up, Power feedback should be used; the control program can be configured to change feedback mode automatically.

The Transfer mode can be selected as I^2 to P or I_{rms} to P as appropriate to the type of load being controlled.

None	No feedback parameter transfer to the control program.
I^2	Selects transfer mode: I^2 to the selected Feedback Mode (above).


4.2.4 Limitation features

In order, for example, to prevent potentially damaging inrush currents, it is possible to set a value for power or Current squared which is not to be exceeded. For loads exhibiting a low impedance at low temperatures but a higher impedance at working temperature, the current drawn reduces as the load warms, and limiting gradually becomes unnecessary.

Section 6.6.3 describes the configuration parameters which allow the user to enter a Process Variable (PV) and a setpoint (SP), where the PV is the value to be limited (e.g. I^2) and the SP is the value that the PV must not exceed.

FIRING ANGLE LIMITING

For phase angle control, limiting is achieved by reducing the firing angle on each half mains cycle such that the limit value of the relevant parameter is not exceeded. As limiting is reduced so the phase angle tends to its target value.



DUTY CYCLE LIMITING

For Burst Firing only, limiting reduces the 'On' state of the burst firing driving the load. Load current, voltage and active power are calculated over the period of each ($T_{on} + T_{off}$) period.

CAUTION

When applied to load current, duty cycle limiting does not limit the peak current value, and under some circumstances this may allow an overheating hazard in the load and/or Power Module to develop.

CHOP OFF

This is a limiting technique which detects an over-current alarm state and stops further thyristor firing for the duration of that alarm state. All the relevant parameters are to be found in the [Network Setup menu](#) (section 6.17.2).

There are two alarms which may trigger Chop Off, as follows:

1. The chop-off alarm becomes active when a current threshold is exceeded for more than a pre-defined number of mains period. This current threshold is user- adjustable from 100% to 400% of unit's nominal current ($I_{Nominal}$).
2. The alarm is active if ChopOff2Threshold is exceeded more than a specified number of times (Number Chop Off) within a specified time period (Window Chop Off). ChopOff2Threshold is adjustable between 100% and 350% inclusive, of $I_{Nominal}$; Number Chop Off can be selected to any value between 1 and 16 inclusive; Window Chop Off can be set to any value between 1 and 65535 seconds (approximately 18 hours 12 mins.).

Each time the threshold is exceeded, the unit stops firing, raises a chop off condition alarm, then after 100ms, restarts using an up-going safety ramp. The condition alarm is cleared if the unit successfully restarts. If the alarm is raised more than the specified number of times within the specified window, then the Chop Off alarm is set and the unit stops firing. Firing is not resumed until the operator acknowledges the Chop Off alarm.

5 CONFIGURATION FROM THE FRONT PANEL

At power up or after quitting the Quickcode menu, the unit initialises and then enters the summary page (figure 5.1) showing the real-time values of the two parameters selected in Instrument Display configuration (section 6.11.2).





Figure 5 Initialisation screens

If any faults are detected during initialisation (e.g. supply voltage missing), then error messages appear on the display screen.

5.1 MENU PAGES

Operating the return key opens the first page of the menu, the content of which depends on the current access level and on the number of options enabled.

The description below assumes 'Configuration' level access.



5.1.1 Comms menu

This allows the following communications parameters to be viewed or configured.




Figure 5.1.1 Comms menu

Comms	Displays (read only) the current IP and Subnet mask addresses.
IP Mode	Allows the user to select 'Fixed' or 'DHCP' as the IP address source. If 'Fixed' is selected, then the Address and Subnet Mask can be edited in the following fields. It must be ensured that the address is unique to the network. If DHCP is selected, the IP Address and SubNetMask parameters described below do not appear. DHCP will be successful only if there is a suitable DHCP server on the network to which the unit is connected.
IP Address	Appears only if 'Fixed' is selected as IP Mode (above). Allows the user to edit the current IP address. Example: To set an IP address of 111.112.113.1, use the up and down arrow pushbuttons to set the first section of the address to 111. Use the enter key, and then the up and down pushbuttons to set the second section to 112. Use the enter key, and then the up and down pushbuttons to set the third section to 113. Use the enter key, and then the up and down pushbuttons to set the fourth section to 1 (not 01 or 001). Use the Enter key to quit Edit mode. If any section is already as required, it can be skipped by using the Enter key.
SubNetMask	Set the subNet mask as described above for the IP address.
Link Speed	Select the required link type and speed.

Note... For details about subnet masks, see [section 7.1.3 \(iTools wiring\)](#).

5.1.2 Config menu

This menu allows a number of network and firing output parameters to be set up, as well as Analogue input and IP mode types.




Figure 5.1.2 Config menu

VLine Nominal	Line voltage nominal value (Line to neutral)
I Nominal	Nominal current supplied to the load
Firing Mode	Firing Mode. Allows the firing mode to be selected as Burts Var, Burst Fix, Logic, Phase Angle (PA) or Intelligent half cycle (IHC). See section 6.9 for more details.
Ana_in type	Select the Analogue Input type as 0 to 10V, 1 to 5 V, 2 to 10V, 0 to 5V, 0 to 20mA, 4 to 20mA.
Soft Start	For Burst Firing only, this is the soft start duration, in supply voltage cycles, applying a phase angle ramp at the beginning of each on period. See section 6.9 for more details.
Soft Stop	In Burst Firing, the soft stop duration, in supply voltage cycles, applying a phase angle ramp at the end of each on period. See section 6.9 for more details.
PLF Adjust R	When the process has achieved a steady state condition the operator must set the PLF AdjustReq. This makes a load impedance measurement to be used as a reference for detecting a partial load failure. If the load impedance measurement is successful 'PLF Adjusted' is set. The measurement fails if the load voltage (V) is below 30% of VNominal or if the current (I) is below 30% of INominal. The input is edge sensitive, so if the request is made from external wiring, and the input remains permanently at a high level, only the first 0 to 1 edge is taken into account.
PLF Adjusted	A sucessful load impedance measurement has been made (see PLF Adjust R above).

5.1.3 Meas menu

This menu allows the user to view a number of measured values in real time. For further details, see 'Network Meas Menu' (section 6.17.1).




Figure 5.1.3 Meas menu

5.1.5 Alarm Relay menu

This menu allows the user to select which alarms are to operate (de-energise) the relay. For each selected alarm, select 'Yes' or 'No'.




Figure 5.1.5 Alm relay menu

5.1.6 Info menu

This display gives read only information about the unit.




Figure 5.1.6 Info menu

5.1.7 Access menu

Allows access to the Operator, Engineer, Configuration and Quick Code menus and allows passwords to be set up. Alarms can also be viewed in this menu.




Figure 5.1.7 Access menu

Goto	Allows access level to be selected.
Pass Code	Allows the user to enter the code for the access level required.
Config Code	Allows the user to edit the Configuration access level code
Engineer Code	Allows the user to edit the Engineer access level code
Quick Code	Allows the user to edit the Quik code access code
Alarms	Any active alarms appear, and details can be found by selecting the relevant alarm and using the Enter push button (Section 5.1.6, below).

Note...The default access codes are Operator = 0, Engineer = 2, Config = 3, Quickcode = 4.

5.1.7 ACCESS MENU (Cont.)

ACCESS TO MENUS

1. Open the Access menu item.
2. Open the Goto menu item and select the access level required.
3. Enter the access code for the level required. If this access code is correct the relevant menu appears.

Note... The above applies only when the user attempts to access a higher level than that current. If accessing a lower level, the user needs only to open the Goto item and select the required level. After doing this, the instrument will probably restart.

5.1.8 Alarms menu

Allows the user to view Global acknowledgement enable status, and calibration error (if any). Any active alarms appear, and details can be found by selecting the relevant alarm and using the Enter push button. Active alarms can be acknowledged, if applicable, by a further operation of the Enter button.




Figure 5.1.8 Alarms menu

6 CONFIGURATION USING ITOOLS

6.1 INTRODUCTION


Note: Section 6 contains descriptions of all the menus which can appear. If an option or a feature is not fitted and/or enabled, then it does not appear in the top level menu.

Section 7 details how to connect using iTools and gives details of the features available from this instrument.

6.2 OVERVIEW

The configuration of the unit is divided into a number of separate areas as follows:

Access	Section 6.3	Lgc2	Section 6.13
Alarm	Section 6.4	Lgc8	Section 6.14
Comms	Section 6.5	Math2	Section 6.15
Control	Section 6.6	Modulator	Section 6.16
Energy	Section 6.7	Network	Section 6.17
Fault Detection	Section 6.8	QCode	Section 6.18
Firing o/p	Section 6.9	Setpoint provider	Section 6.19
I/O	Section 6.10	User values	Section 6.20
Instrument	Section 6.11	Diagnostics	Section 6.21
IP Monitor	Section 6.12		



iTools tree

Notes:

1. Current rating, limitation, transfer control, power control, energy counter and the graphical wiring editor (GWE) are chargeable options. iTools secure can be used to upgrade units.
2. 32A unit are set on 16A and 63A unit are on 40A by default.

6.3 ACCESS MENU




Figure 6.3 iTools Access menu

Goto	Select access level
Passcode	Select relevant pass code for the access level required.
EngineerPasscode	Passcode for Engineer level access
ConfigurationPasscode	Passcode for Configuration level access
QuickCodePasscode	Passcode for Quickcode menu
UPGPass	Passcode for upgrading device
Clear memory	When available and set to 'yes', the device clears all configuration data, performs a cold-start and enters the Quickcode mode.

6.4 ALARM CONFIGURATION




Figure 6.4 Alarm configuration

Main	'ExternIn' is the input of this block. When connected to digital input 2 (DI2) and DI2 connected to a fuse blown detection contact, this alarm is considered as a 'fuse blown' alarm
AlarmDis	This allows the listed alarm to be enabled or disabled. 0 = Enable; 1 = Disable
AlmDet	This parameter indicates whether the alarms has been detected and is currently active. 0 = Inactive; 1 = Active
AlmSig	Signals that the alarm has occurred and is possibly latched by the Alarm Latch settings. If the user wishes to assign an alarm to, for example, a relay then it is the appropriate AlmSig parameter that should be wired. 0 = Not Latched; 1 = Latched.
AlmLat	The alarm can be configured as latching or non-latching, the latched state being shown in the Alarm Signal (AlmSig) register. 0 = Non-Latching; 1 = Latching.
AlmAck	Allows the alarm to be acknowledged. When an alarm is acknowledged, its related signalling (AlmSig) parameter is cleared. If the alarm is still active (as shown by the detection (AlmDet) parameter) then the alarm cannot be acknowledged. The acknowledge parameters automatically clear after being written. 0 = Do not acknowledge; 1 = Acknowledge
AlmStop	Allows the alarm to be configured such that it stops the related power channel firing. AlmStop is activated by the signalling parameters and thus may be latching. 0 = Do not stop; 1 = Stop.

6.5 COMMUNICATIONS CONFIGURATION

The communications menu allows the user to view, and in some cases, to edit communications parameters associated with the communications option.




Figure 6.5b iTools comms page

Host name	<p>The name of the device on the link-local network.</p> <p>For convenience, the device can declare itself on the pseudo-domain .local. If the host-name of the device is changed, it must be ensured that the name is unique on the network. In this is not the case, the instrument will transparently try to find another unique name automatically.</p> <p>The default value is related to the MAC address of the device and thus should already be unique.</p>
SRV name	MBUS name. The name of the device, as shown by iTools
IP Mode	<p>The IP configuration mode of the instrument.</p> <p>0: Static. The IP parameters are taken from the parameter IPAddr, SubNetMark and NetGateway.</p> <p>1: DHCP. The IP address of the instrument is automatically assigned by an external DHCP server. If the instrument fails to acquire an IP address, the auto IP mechanism assigns an IP to the instrument in the range 169.254.xxx.xxx with subnet mask 255.255.0.0.</p>
IP Status	This (hidden) parameter describes the current status of the IP address of the instrument.
IP	This is the current IP address of the device which may be different from the configured IP address.
cSubnetMask	The current subnet mask associated with 'IP' above.
cDefault Gateway	The current default gateway associated with 'IP' above.
Pref Master	The IP address of the preferred host.
Address	On a network of instruments this address is used to specify a particular instrument. Each instrument on a network must be set to a unique address, the available address range depending upon the network protocol. As EPack supports only Modbus/TCP protocol, and discrimination on the network is carried out using the IP addresses of the connected instruments, the modbus addresses of the devices are not used.
IP address	The configured IP address of the device
Subnet Mask	The subnet mask associated with 'IP address' above.
Default Gateway	The default gateway associated with 'IP address' above.

6.5 COMMUNICATIONS MENU (Cont.)

MAC12	First two Bytes of the MAC Address 11-22 -33-44-55-66
MAC34	Second two Bytes of the MAC Address 11-22- 33-44 -55-66
MAC56	Third two Bytes of the MAC Address 11-22-33-44- 55-66
Timeout	Comms timeout value in ms. If no usercomms request arrives twithin the time specified in this parameter, the Fallback values will change.
Fallback1	Set to 1 when a communication timeout has not occured; set to zero if a timeout occurs.
Fallback2	Inverse value of the Fallback1 parameter.
En Timeout	If set to ON (1), the timeout of the comms requests will be monitored. The outputs Fallback1 and Fallback2 will be adjusted accordingly. 0 =Off. 1= On
Protocol	Main communication protocol to access the instrument over ethernet comms. 0 = Modbus TCP
IO gateway	IP address of IO gateway.
Link Speed	Select a link speed from Auto negotiate, 100MB, 100MB half duplex, 10 MB or 10MB 1/2 duplex.

6.6 CONTROL CONFIGURATION

The control menu provides the control algorithm to perform power control and transfer, threshold limiting and phase angle reduction (in the case of burst firing). Figure 6.6, below, gives an overview of the menu, which is described in the following sections:

- | | | | |
|-------|------------------------|--------|--------------------------------|
| 6.6.1 | Setup | 6.6.6 | AlmDet (Alarm detection) |
| 6.6.2 | Main | 6.6.7 | AlmSig (Alarm Signalling) |
| 6.6.3 | Limit | 6.6.8 | AlmLat (Alarm latching) |
| 6.6.4 | Diag (Diagnostics) | 6.6.9 | AlmAck (Alarm Acknowledgement) |
| 6.6.5 | AlmDis (Alarm disable) | 6.6.10 | AlmStop (Stop firing on alarm) |




Figure 6.6 Control menu overview

6.6.1 Control setup menu

This contains parameters for setting the type of control to be performed.





Figure 6.6.1 Control setup page

PARAMETERS

Standby	If Yes (1), the controller enters Standby mode and zero % power is demanded. When removed from Standby (0) the unit returns to operating mode in a controlled manner.
Nominal PV	Normally the nominal value for each control type. For example, for feedback mode = V^2 , V_{sq} should be wired to the Main PV, and Nominal PV set to the nominal value expected for V^2 (usually $V_{LoadNominal}^2$).
En Limit	Used to enable/disable threshold limit.
Transfer En	Select Transfer Enable (Proportional limit) as 'Yes' (enabled) or 'No' (not enabled).
FF Type	Feedforward Type. Off (0). Feedforward is disabled Trim (1). Feedforward value is the dominant element of the output. Trimmed by the control loop based on the Main PV and setpoint. FFOnly (2). The feedforward value is the output from the controller. Open loop control may be configured by this means.
FF Gain	The entered gain value is applied to the Feedforward input.
FF Offset	The entered value is applied to the Feedforward input after the Gain value has been applied to it.
Bleed Scale	Internal parameter for use by service personnel

6.6.2 Control Main menu

This menu contains all the parameters associated with the Main control loop.



Name	Description	Address	Value	Wired From
PV	The main PV of the controller	1064	0.00	Network.Meas.Vsq
SP	Main SP to control at	1065	0.00	SetProv.WorkingSP
TI	Integral time of the main loop	1068	3.20	

Control.Main - 5 parameters


Figure 6.6.2 Control 'Main' menu

PARAMETERS

PV	Displays the main Controller Process Variable (PV). Wired to the measurement which it is to be controlled. For example, to perform V ² control. Vs _q should be wired to this (PV) parameter and Nominal PV configured appropriately.
SP	The Setpoint to control at, as a percentage of Nominal PV (the upper range of the loop in engineering units). For example, if Vs _q = 193600, and SP is set to 20%, the controller attempts to regulate at 193600 x 20/100 = 38720.
Trans PV	Transfer PV. This is the PV measurement for transfer. For example, if a V ₂ to I ₂ transfer is required, the Vs _q should be wired to MainPV and Is _q to TransferPV. Appears only if Trans Enable (section 6.6.1) is set to 'Yes'.
Trans SP	The span of operation for transfer. Appears only if Trans Enable (section 6.6.1) is set to 'Yes'.
TI	Allows the user to define an integral time for the main PI control loop.

6.6.3 Control limit configuration

This area configures parameters relating to the limit control loop.



Name	Description	Address	Value
PV1	Threshold Limit PV1	1069	0.00
PV2	Threshold Limit PV2	1070	0.00
PV3	Threshold Limit PV3	1071	0.00
SP1	Threshold limit setpoint 1	1072	0.00
SP2	Threshold limit setpoint 2	1073	0.00
SP3	Threshold limit setpoint 3	1074	0.00
TI	Integral time of the limit loop	1075	1.00

Control.Limit - 7 parameters

Figure 6.6.3 Control limit menu

PARAMETERS

PV1 to PV3	Threshold value for limit loops 1 to 3 respectively. This is the value to perform threshold limit control. 'Limit Enable' must be set to 'Yes' in the Setup menu (section 6.6.1).
SP1 to SP3	The setpoint for limit loops 1 to 3 respectively.
TI	The integration time for the limit PI control loop. The default value is firing mode dependent.

Example:

If I² threshold limiting is required, Is_q is wired to PV1, and the required threshold value is entered at SP1. In phase angle configuration, the phase angle is reduced to achieve the limit setpoint; in burst firing, the unit continues to fire in bursts, but these bursts are of phase angle in order to achieve the limit setpoint. The modulation continues to attempt to reach the main setpoint.

Also known as phase angle reduction burst firing.

6.6.4 Control diagnostic menu




Figure 6.6.4b iTools diagnostic menu

PARAMETERS

Status	Indicates the current operating state of the controller: Main PV The control strategy is using Main PV as the control input Transfr The transfer input us being used as the input to the control strategy. Limit1(2)(3) Control limiting is currently active using limit PV1(2)(3) and limit SP 1(2)(3).
Output	The current output demand in percent. Normally wired to Modulator.In or FiringOP.In
PAOP	Applies only to Burst Firing control modes. If this parameter is wired to Firing.limitIn, the power module will deliver bursts of phase angle firing depending both on the Main Set-point and on the Limit Setpoint.

6.6.5 Control Alarm disable menu

Allows each alarm of the control block to be disabled, individually.




Figure 6.6.5 Alarm disable page

PARAMETERS

Closed Loop	Select Enable (0) or Disable (1) for loop break alarm.
PV Transfer	As for Closed Loop, but for the 'Transfer active' alarm.
Limitation	As for Closed Loop, but for the 'Control limit active' alarm.

6.6.6 Control Alarm detection parameters

Indicates whether each alarm has been detected and whether or not it is currently active.




Figure 6.6.6 Control Alarm detection page

PARAMETERS

Closed Loop	Displays whether or not the closed loop alarm is currently active.
PV Transfer	As for Closed Loop, but for the 'Transfer Active' alarm.
Limitation	As for Closed Loop, but for the 'Control limit active' alarm.

6.6.7 Control Alarm signalling parameters

Signals that an alarm has occurred and has been latched (if so configured in 'Alarm Latch' (section 6.6.8). If it is required that an alarm is to be assigned to a relay (for example), then the appropriate alarm signalling parameter should be used.




Figure 6.6.7 Control Alarm Signalling page

PARAMETERS

Closed Loop	Indicates whether the closed loop break alarm is currently active.
PV Transfer	As for Closed Loop, but for the 'Transfer Active' alarm.
Limitation	As for Closed Loop, but for the 'Control limit active' alarm.

6.6.8 Control Alarm Latch parameters

Allows each alarm to be configured as latching or not latching.




Figure 6.6.8 Control Alarm latching page

PARAMETERS

Closed Loop	Set the latching status of the alarm.
PV Transfer	As for Closed Loop, but for the 'Transfer Active' alarm.
Limitation	As for Closed Loop, but for the 'Control limit active' alarm.

6.6.9 Control Alarm Acknowledgement parameters

This menu allows individual alarms to be acknowledged. On acknowledgement, the related Signalling parameter is cleared. The Acknowledge parameters automatically clear after being written. If the alarm is still active (as shown by the Alarm Detection display) it cannot be acknowledged.




Figure 6.6.9 Control Alarm Acknowledge page

PARAMETERS

Closed Loop	Displays whether the closed loop alarm has been acknowledged or not.
PV Transfer	As for Closed Loop, but for the 'Transfer Active' alarm.
Limitation	As for Closed Loop, but for the 'Control limit active' alarm.

6.6.10 Control Alarm Stop parameters

Allows individual channels to be configured such that it will stop the associated power channel from firing whilst the alarm is active. This feature is activated by the signalling parameters, so the alarm stop may be latching.




Figure 6.6.10b iTools Control Alarm Stop page

PARAMETERS

- Closed Loop Shows whether the closed loop alarm has been configured to disable firing or not.
- PV Transfer As for Closed Loop, but for the 'Transfer Active' alarm.
- Limitation As for Closed Loop, but for the 'Control limit active' alarm.

6.7 ENERGY CONFIGURATION

Provides a number of energy counters to totalise consumed energy. The power consumed can be displayed in one of number of units, ranging from W to GW.




Figure 6.7 Energy configuration page

PARAMETERS

UsrUnit	Allows a scaling units value to be entered for the energy display. Selectable as '1Wh', '10Wh', '100Wh', '1kWh', '10kWh', '100kWh', '1MWh', '10MWh', '100MWh' or '1GWh'.
Input	Shows the instantaneous power input from the measuring source. Normally wired to the Meas.P output of the Network block.
Reset	1 = Energy counter output goes to zero and immediately starts accumulating. 0 = Energy counter not reset.
Hold	1 = Hold output value. This freezes the output value for the block at the current value. The input continues to be totalised, so when the Hold input returns to 0, the output value is instantaneously updated to the new current value. 0 = output value is not held, and represents the current accumulated Energy value.
UsrEnergy	Shows the current value for the selected Energy Counter block.
Autoscale	No = Use UsrUnit setting. Yes = Autoscale power value display (table 6.7, below).

Power range (Watt-hours)	Scaler value
0 to 65535	1
65,535 to 65,535,000	1k
65,535,000 to 655,350,000	10k
655,350,000 to 6,553,500,000	100k
6,553,500,000 to 65,535,000,000	1M
65,535,000,000 to 655,350,000,000	10M
655,350,000,000 to 6,553,500,000,000	100M
6,553,500,000,000 upwards	1G

Table 6.7 Scaler values

6.7.1 Resolution

The resolution of the stored energy value varies according to the totalised value, as shown in table 6.7.1 below. For example, for stored values between 33,554,432 watt-hours and 67,108,863 watt-hours, the value increases in 4 watt-hour increments.

Power range (Watt-hours)	Resolution (W-h)	Power range (Watt-hours)	Resolution (W-h)
0 to 16,777,215	1	17,179,869,184 to 34,359,738,367	2048
16,777,216 to 33,554,431	2	34,359,738,368 to 68,719,476,736	4096
33,554,432 to 67,108,863	4	68,719,476,736 to 137,438,953,471	8192
67,108,864 to 134,217,727	8	137,438,953,472 to 274,877,906,943	16384
134,217,728 to 268,435,455	16	274,877,906,944 to 549,755,813,887	32768
268,435,456 to 536,870,911	32	549,755,813,888 to 1,099,511,627,776	65536
536,870,912 to 1,073,741,823	64	1,099,511,627,776 to 2,199,023,255,551	131072
1,073,741,824 to 2,147,483,647	128	2,199,023,255,552 to 4,398,046,511,103	262144
2,147,483,648 to 4,294,967,295	256	4,398,046,511,104 to 8,796,093,022,207	524288
4,294,967,296 to 8,589,934,591	512	8,796,093,022,208 to 17,592,186,044,415	1048576
8,589,934,592 to 17,179,869,183	1024		

Table 6.7.1 Energy counter resolution

6.8 FAULT DETECTION MENU

This manages Alarm logging and provides an interface for the General Alarm Acknowledgement.




Figure 6.8 Fault detection menu page

PARAMETERS

General Ack	Performs a global acknowledgement of alarms. Latched alarms are cleared if their trigger sources are no longer in an alarm state. Wired by default from Digital input 2.
AlarmAck	Enables global alarm acknowledgement from front fascia.
Any Alarm	'Active' indicates that there is one or more System, Process or 'Chop Off' alarm active. If the relevant alarms are enabled, System alarms and Chop Off alarms always cause the power module to stop firing. Process alarms can also be configured to prevent firing in 'Alarm stop'.
NetProcAl	Indicates that a process alarm has occurred in the power network.
AnySysAlm	Indicates that a systems alarm is active. By default, this is wired to IO Relay.PV.
Custom Alarm	Indicates that an alarm using rules defined by user, is active. (See AlmRelay tab in corresponding function block)
Global Disable	Allows the user to disable/enable all alarms.
StratStatus	A coded status word giving strategy information as shown in table 6.8a
Alarm Status 1(2)	Two 16-bit words containing alarm status information as shown in tables 6.8b and 6.8c.

Bit	Value	Description
0	1	Network not firing
1	2	Network not synchronising
2	4	Reserved
3	8	Reserved
4	16	Reserved
5	32	Reserved
6	64	Reserved
7	128	Reserved
8	256	Strategy in standby mode
9	512	Strategy in Telemetry mode
10	1024	Reserved
11	2048	Reserved
12	4096	Reserved
13	8192	Reserved
14	16384	Reserved
15	32768	Reserved

Table 6.8a Strategy status

6.8 FAULT DETECTION MENU (Cont.)

Bit	Value	Description	Bit	Value	Description
0	1	Missing mains	0	1	Closed loop
1	2	Thyristor short circuit	1	2	Transfer active
2	4	Over temp*	2	4	Limit active
3	8	Network dips	3	8	Reserved
4	16	Frequency fault	4	16	Reserved
5	32	Total Load Failure	5	32	Reserved
6	64	Chop off	6	64	Reserved
7	128	Partial load failure	7	128	Reserved
8	256	Partial load unbalance*	8	256	Any bit in Global Status 0
9	512	Over voltage	9	512	Any bit in Global Status 1
10	1024	Under voltage	10	1024	Any bit in Global Status 2
11	2048	Pre temp*	11	2048	Any bit in Global Status 3
12	4096	Over current	12	4096	Reserved
13	8192	Reserved	13	8192	Reserved
14	16384	Analogue input over C	14	16384	Reserved
15	32768	External input	15	32768	Reserved

Table 6.8b Alarm status word 1

Table 6.8c Alarm status word 2

* Note... These alarms not applicable at this release but are reserved for future development.

6.9 FIRING OUTPUT MENU

This forms the link between the control strategy and the physical load. This block also supplies Phase-Angle Ramp (Soft start) and Safety Ramp.




Figure 6.9 iTools configuration firing output page

Mode	Displays the current firing mode as Intelligent half cycle (IHC), Burst firing, Phase angle firing or no mode. Configured in the 'Modultr', menu described below.
Load Type	Allows the load type to be selected as 'Resistive' or 'Transformer'. For Load type = Resistive, the load must be connected directly to the power module and only resistive loads may be so connected. For Load Type = Transformer, the load is connected to the power module via a transformer, and may be resistive or reactive.
Safety Ramp	Displays the safety ramp duration, in supply voltage cycles (0 to 255), to be applied at startup. The ramp is either a phase angle ramp from zero to the requested target phase angle or, for Burst Firing, from 0 to 100%. See figure 6.9.1a. Safety Ramp is not applicable to Half cycle Mode.
Soft Start	For Burst Firing only, this is the soft start duration, in supply voltage cycles, applying a phase angle ramp at the beginning of each on period (figure 6.9.1b).
Soft Stop	In Burst Firing, the soft stop duration, in supply voltage cycles, applying a phase angle ramp at the end of each on period
Delayed Trigger	Appears only if Mode = Burst, Soft Start = Off, and Load Type = TxFormer. Delayed Trigger specifies the triggering delay, in phase angle, when delivering power into a transformer load. Used to minimise inrush current. the value is configurable between 0 and 90 degrees inclusive (figure 6.9.1c).
Enable	Enables/disables firing. Must be wired to a non-zero value to enable firing (typically a digital input).
In	Displays the input power demand value that the power module is to deliver.
PA Limit	Phase angle limit. This is a phase angle reduction factor used in Burst Firing. If lower than 100% the power module will deliver a burst of phase angle firing. Used, typically, to perform threshold current limiting in Burst Firing.
Ramp Status	Displays the safety ramp status as 'Ramping' or 'Finished'.

6.9.1 Examples




Figure 6.9.1a Safety ramp (burst firing) examples




Figure 6.9.1b Soft start example




Figure 6.9.1c Delayed trigger definition

Note: Waveforms have been idealised for clarity.

6.10 INPUT/OUTPUT (IO) CONFIGURATION

This area of configuration allows the user to configure the analogue and digital inputs and to view the status of the Relay output. The configuration is separated into the following areas:

AI (analogue inputs) [Section 6.10.1](#)

Digital inputs 1 and 2 [Section 6.10.2](#)

Relay output [Section 6.10.3.](#)




Figure 6.10 Top level IO menu

6.10.1 Analogue input configuration

The configuration for the analogue input is divided into a number of areas:

- Main,
- AlmDis,
- AlmDet,
- AlmSig,
- AlmLat,
- AlmAck,
- AlmStop,
- AlmRelay.

AI MAIN




Figure 6.10.1b iTools analogue input page

PARAMETERS

- Type Allows the type of input to be set as one of: 0 to 10V, 1 to 5V, 2 to 10V, 0 to 5V, 0 to 20mA, 4 to 20mA. For pinout details, see [figure 2.2.3](#).
- RangeHigh High range of input for scaling from measurement units to process units. PV is clipped to range high if input goes over range.
- RangeLow Low range of input for scaling from measurement units to process units. PV is clipped to range low if input goes under range.
- PV The scaled value in process units. Clipped to the Range High or Range Low value if the signal goes over range or under range respectively.
- MeasVal The value at the instrument terminals in electrical units.

ALMDIS

Allows the user to enable or disable alarms individually

EXAMPLE

The figure below shows an iTools page for ALMDIS. Pages for the other ALM parameters are similar.




Figure 6.10.1c AlmDis example

ALMDET

Indicates whether each individual alarm has been detected and is currently active.

6.10.1 ANALOGUE INPUT CONFIGURATION (Cont)

ALMSIG

Signals that an alarm has occurred, and whether or not it is a latched. If the user wishes to assign an alarm to for example a relay then the appropriate signalling parameter should be wired.

ALMLAT

Allows each individual alarm to be configured as latching, the latched state is shown in the alarm signalling parameter

ALMACK

Allows each individual alarm to be acknowledged. On an alarm being acknowledged the related signalling parameter (ALMSIG) is cleared. If the alarm is still active as shown by the detection parameter (ALMDET) the alarm may not be acknowledged. The acknowledge parameters automatically clear after being written.

ALMSTOP

Allows each individual alarm type to be configured to stop the power channel firing. ALMSTOP is activated by the signalling parameter (ALMSIG) and may be latching or not according to the ALM LAT setting for the alarm.

ALMRELAY

Causes the relay to be controlled by this alarm

6.10.2 Digital input configuration

This allows the user to configure each of the digital inputs.




Figure 6.10.2b iTools Digital input configuration page

PARAMETERS

Type	Select Logic Input (IP Volts) or IPContact. For pinout details, see figure 2.2.3 .
Invert	Sets the inversion status to 'No' or 'Yes'. When set to 'No', there is no inversion (e.g. if MeasVal = 0 then PV = 0). When set to 'Yes', an inversion takes place (e.g. if MeasVal = 0 then PV = 1)
PV	The current state of the input, after any inversion has been applied.
MeasVal	For inputs, this shows the value measured at the instrument terminals, in electrical units.

6.10.3 Relay status




Figure 6.10.3b iTools relay status page

PARAMETERS

- PV This shows the status of the input to the relay as either 'On' (True) or 'Off' (False).
 - Meas Val Shows the current state of the relay coil. 1 = energised; 0 = de-energised, where 'ener-gised' is 'off' and 'de-energised' is 'on'.
- For pinout details, see [figure 2.2.3](#). For specification, see [section A2](#)

6.11 INSTRUMENT CONFIGURATION MENU

Instrument configuration is divided into the following sections:

Display [Section 6.11.1](#)

Configuration [Section 6.11.2](#)

Options [Section 6.11.3](#)

Scaling Factor [Section 6.11.4](#)




Figure 6.11 Top level instrument configuration page

6.11.1 Instrument display configuration




Figure 6.11.1 Instrument display configuration page

PARAMETERS

Language	Select required language for subsequent displays.
Serial No	Read only. Displays the factory-set Serial number of the unit.
Dev Name	The device name as it appears at the user display.
Label 0(1)	The text that appears on the home page for the two parameters defined by the addresses listed in Param0 and Param1. User-definable 3 characters (maximum).
Param0(1)MB	This is the modbus address of the first (second) parameter to be displayed in the home screen of the instrument.

6.11.2 Instrument Config configuration

The current hardware configuration.




Figure 6.11.2 Instrument configuration

PARAMETERS

Net Type	Network type. This is set at the factory and cannot be changed by the user. 1 = Single phase
Power Type	0 = 32A; 1 = 63A This is set at the factory and cannot be changed by the user.
Timer Res	Resolution of time parameters 0 = 10ths of seconds (100ms); 1 = 10ths of minutes (6 seconds)
Software	Software version of the product.

6.11.3 Instrument options configuration




Figure 6.11.3 Instrument options configuration page

PARAMETERS

SerialNo	The instrument serial number.
Software	The version of software running on this instrument
Passcode1 (2)(3)	Pass Code for Features Secure Word 1(2)(3).

6.11.4 Scaling Factor

Allows scaling factors to be entered for a number of parameters. In iTools, the scaling factors are arranged in 'tabs' of which, for the sake of clarity, this document depicts only one (SetProv).

These scaling factors are applied in modbus transactions when access to relevant parameters is made using low range address (i.e. not the IEEE region).





Figure 6.11.4 Scaling factor top level menu.

SETPROV EXAMPLE



In the above example it can be seen that all the Set point provider parameters are scaled x100, except for Ramp Rate which is not scaled (i.e. the scaling factor = 1). As can also be seen, the scaling factors available are x1, x10, x100, x1000, ÷10, ÷100, ÷1000.

If the LocalSP, for example, has a scaling factor of x100, as above, then a value of say 5000 means in fact that the real value is 50.00.

Notes:

- 1 The above example shows the default scaling formats set - they are User configurable.
- 2 Values are rounded up/down.

6.12 IP MONITOR CONFIGURATION

This monitors a wired parameter and records its maximum value, minimum value and the cumulative time that its value spends above a configurable threshold. An alarm can be set up to become active when the time-over-threshold exceeds a further threshold.




Figure 6.12b iTools input monitor page (IPMon1)

PARAMETERS

In	The parameter to be monitored. Normally wired (using iTools) to a parameter, but a numeric entry can be made for testing purposes.
Max	The maximum value reached by the parameter since last reset.
Min	The minimum value reached by the parameter since last reset.
Threshold	This value acts as a trigger for the 'Time Above' measurement.
Days above	Shows how many complete days the parameter value has spent above the Threshold value (continuously or intermittently) since last reset. The 'Time Above' value should be added to 'Days Above' in order to find the total time.
Time Above	Shows how many hours, minutes and tenths of minutes that the parameter value has spent above the threshold value (continuously or intermittently) since last reset, or since the last complete day. (once the value exceeds 23:59.9, the 'Days Above' value is incremented and 'Time Above' is reset to 00:00.0.) The 'Time Above' value should be added to 'Days Above' in order to find the total time.
Alarm Days	Together with 'Alarm Time' this defines a 'total time above threshold' value, which, when exceeded, sets the Alarm out parameter 'On'.
Alarm Time	See 'Alarm Days' above.
Reset	Resetting causes the Max. and Min. values to be set to the current value, sets the 'Days Above' value to zero, and the 'Time Above' value to 00:00.0.
Status	Shows the status of the input parameter as either 'Good' or 'Bad'.

6.13 LGC2 (TWO INPUT LOGIC OPERATOR) MENU

This logic operator block provides a number of two-input logic operations. The output is always a 'Boolean' (logic 0 or 1) no matter whether the inputs are analogue or digital. For analogue inputs, any value below 0.5 is deemed to be logic 0 (off). A value equal to or greater than 0.5 is treated as a logic 1 (on).

Either input can be 'inverted' as a part of the configuration (that is, a high input is treated as a low input and vice-versa.)




Figure 6.13 Lgc2 page (Lgc2 1)

6.13.1 Lgc2 Parameters

Oper	Allows the user to select a logic operation for the block. The descriptions below assume neither input is inverted. High = 1 or on; Low = 0 or off.
Off	No logic operation selected.
AND	Out is high if both inputs high, otherwise Out is low.
OR	Out is high if either or both inputs high, otherwise Out is low.
XOR	Output high if either (but not both) inputs high. Low if neither or both inputs are high.
Latch	If In2 low, Out latches next transition of In1. Value remains latched until In2 goes low, when Out = In1 (see figure 6.13.1).
Equal	Out high if both inputs are equal, otherwise output is low.
Not Equal	Out is high if inputs are unequal. Out is low if inputs are equal.
Greater than	Out is high if In1 value greater than In2 value, otherwise Out is low.
Less than	Out is high if In1 value less than In2 value, otherwise Out is low.
GreaterEqual	Out is high if In1 value is equal to or greater than In2 value, otherwise Out is low.
LessEqual	Out is high if In1 value is less than or equal to In2 value, otherwise Out is low.
In1	If wired, shows the value of In1; if not, allows the user to enter a value.
In2	If wired, shows the value of In2; if not, allows the user to enter a value.
Fallback type	Allows a fallback type to be selected. This defines the output value and status displays if the status of one or both inputs is 'bad'.
FalseBad	Output value displays 'False' ; Status displays 'Bad'
TrueBad	Output value displays 'True' ; Status displays 'Bad'
FalseGood	Output value displays 'False' ; Status displays 'Good'
TrueGood	Output value displays 'True' ; Status displays 'Good'.
Invert	Allows none, either or both inputs to be inverted.
Out	Shows the current output value

6.13.1 LGC2 PARAMETERS (Cont.)

Status	Shows the status of the output ('Good' or 'Bad').
Hysteresis	For comparison operators only (e.g. Greater than) this allows a hysteresis value to be entered. For example, if the operator is 'Greater than' and hysteresis is H, then the output goes high when In1 exceeds In2, and remains high until In1 falls to a value less than (In2 - H). Not applicable to the 'Equal' function.





Figure 6.13.1 Hysteresis



When In2 goes low, Out follows the next positive or negative transition of In1 (points 'X') and latches at this value until In2 goes high. When In2 is high, Out follows In1.

Figure 6.13.2 Latch operation

6.14 LGC8 (EIGHT-INPUT LOGIC OPERATOR) CONFIGURATION

This allows between 2 and 8 inputs to be combined using an AND, OR or Exclusive OR (EXOR) logic function. The inputs may be individually inverted, and the output can also be inverted, thus allowing the full range of logic functions to be implemented.




Figure 6.14 Lgc8 configuration page

6.14.1 Parameters

Oper	Allows selection of AND, OR or Exclusive OR functions (or OFF). AND = output is high only if all inputs are high OR = output is high if any or all inputs are high XOR = output is high if an odd number of inputs are high, and low if an even number of inputs are high. Logically, a cascaded XOR function: $(((((In1 \oplus In2) \oplus In3) \oplus In4) \dots \oplus In8))$
NumIn	Status = Bit to bit OR of the inputs concatenated into a word. Set the number of inputs to between two and eight inclusive. This number defines how many invert keys appear in 'Invert', and how many Input value pages appear.
InInvert	Allows the user to invert individual inputs, as described below.
Out Invert	No = normal output; 'Yes' means that the output is inverted, allowing NAND and NOR functions to be implemented.
In1	The state (on or off) of the first input
In2 onwards	The state of the remaining inputs
Out	The Output value of the function (i.e. On or Off)

6.14.2 Inversion schematic




Figure 6.14.2 LGC8 inversion Schematic

6.15 MATH2 MENU

This feature allows a range of two-input mathematical functions to be performed. The available functions are listed below.




Figure 6.15 Maths2 configuration page

6.15.1 Math 2 Parameters

Note: For the sake of this description, 'High', '1' and 'True' are synonymous, as are 'Low', '0' and 'False'.

Oper	Defines the mathematical function to be applied to the inputs
None	No operation.
Add	Adds input one to input two.
Sub	Subtracts input two from input one.
Mul	Multiplies inputs one and two together.
Div	Divides input one by input two.
AbsDif	The difference in value between inputs one and two, ignoring sign.
SelMax	Output = the higher of inputs one and two.
SelMin	Output = the lower of inputs one and two.
HotSwap	Input one appears as the output for as long as input one is 'good'. If input one status is bad, input two appears as the output instead.
SmpHld	Sample and Hold. The output follows input one, for as long as input two is high (sample). When input two goes low (hold), the output is held, at the value current when the output went low, until input two goes high again. Input two is normally a digital value (low = 0 or high = 1); when it is an analogue value, then any positive non-zero value is interpreted as a high.
Power	Output = Input one raised to the power of input two (In1^{In2}). For example if input one has the value 4.2, and the value of input two is 3, then output = $4.2^3 = 74.09$ (approx.).
Sqrt	The output is the square root of input one. Input two is not used.
Log	Log base 10: Output = $\{\text{Log}_{10}(\text{In1})\}$. Input two is not used.

6.15 MATH2 PARAMETERS (Cont.)

Oper (Cont.)	Ln	Log base e: Output = $\{\text{Log}_n (\text{In1})\}$. Input two is not used.
	Exp	Output = $e^{(\text{input one})}$. Input two is not used.
	10_x	Output = $10^{(\text{input one})}$. Input two is not used.
	Sel1	If the Select input is high, input two appears at the output; if the Select input is low, input one appears at the output.
In1(2) Mul	The scaling factor to be applied to input one (two).	
Units	Allows the user to choose units for the output (figure 6.15b, above).	
Resolution	Use the up and down arrows to position the decimal point as required.	
Low Limit	The low limit for all inputs to the function and for the fallback value.	
High Limit	The high limit for all inputs to the function and for the fallback value.	
Fallback	The fallback strategy comes into play if the status of the input value is 'Bad', or if its value lies outside the range (High limit- Low limit).	
	Clip Bad	The output is set to the high or low limit as appropriate; output status is set to 'Bad'.
	Clip Good	The output is set to the high or low limit as appropriate; output status is set to 'Good'.
	Fall Bad	The output is set to the fallback value (below); output status is set to 'Bad'.
	Fall Good	The output is set to the fallback value (below); output status is set to 'Good'.
	Upscale Bad	The output is set to the high limit and Status is set to 'Bad'.
	Downscale Bad	The output is set to the low limit and Status is set to 'Bad'.
Fallback value	Allows the user to enter the value to which the output is set for Fallback = Fall Good, or Fall Bad.	
Select	Editable only if Oper = Select. Allows input one or input two to be selected for output.	
In1	Input one value	
In2	Input two value	
Out	The output value resulting from the configured mathematical operation. If either input is 'Bad', or if the result is out of range, the fallback strategy is adopted.	
Status	Indicates the status of the operation as 'Good' or 'Bad'. Used to flag error conditions and can be used as an interlock for other operations.	

6.16 MODULATOR CONFIGURATION

This function implements the modulation type firing modes such as fixed and variable period modulation.

Note... For the sake of completeness, all Modulator parameters are shown in the figure below. Normally, for the sake of clarity, non-relevant (shaded) parameters should be hidden using the 'Options>Parameter Availability Settings...>Hide Parameters and Lists when Not Relevant' menu item.




Figure 6.16 Modulator menu page

6.16.1 Modulator parameters

Mode	Select the required firing mode from 'Logic', 'PA' (Phase angle) 'Half cycle', 'BurstVar' (Burst firing - minimum on time) or 'BurstFix' (Burst firing - cycle time).
In	This is the value that the modulator is required to deliver.
Out	The output logic signal controlling the power module on and off times, normally wired to the input of the firing block. For Mode = Phase angle, this is a phase angle demand.
Min On Time	For Variable Period Modulation, this sets the minimum on time in supply voltage periods. At 50% demand from the modulator, Ton = Toff = Minimum on time, and Cycle time is 2 x Minimum on time = Modulation period. The minimum off time is equal to 'Min on time'.
Cycle Time	For Fixed Period Modulation, this is the cycle time in supply voltage periods.
Logic Mode	For Logic Firing Modulation, Half cycle sets firing stop to the next zero crossing; Full cycle sets firing stop at the zero crossing of the next full cycle.
Switch PA	Allows the user to impose Phase Angle firing, overriding the configured Burst Mode as displayed in 'Mode', above.
PLMin	Not applicable to this software release.

6.17 NETWORK CONFIGURATION

This identifies the type of electrical network to be controlled, and this, in turn defines how the network's electrical measurements are presented. The configuration is divided into a number of areas:

Meas,

Setup

AlmDis,

AlmDet,

AlmSig,

AlmLat,

AlmAck,

AlmStop


AlmRelay.

Name	Description	Address	Value
Frequency	Frequency of the line	267	0.00
Vline	Line voltage measurement	256	0.00
I	Irms of the load	257	0.00
IsqBurst	Average square value of load	258	0.00
Isq	Square value of the load current	259	0.00
V	Vrms of the load	260	0.00
VsqBurst	Average square value of the	268	0.00
Vsq	Square value of load voltage	261	0.00
PBurst	True Power measurement in	262	0.00
P	True power measurement.	263	0.00
S	Apparent power measurement	264	0.00
PF	Power Factor	265	0.00
Z	Load impedance	266	0.00
HtSinkTemp	Heatsink 1 temperature	269	0.00

Network.Meas - 14 parameters

Figure 6.17 Network configuration - top level

6.17.1 Network Meas Menu



Name	Description	Address	Value
Frequency	Frequency of the line	267	0.00
Vline	Line voltage measurement	256	0.00
I	Irms of the load	257	0.00
IsqBurst	Average square value of load	258	0.00
Isq	Square value of the load current	259	0.00
V	Vrms of the load	260	0.00
VsqBurst	Average square value of the	268	0.00
Vsq	Square value of load voltage	261	0.00
PBurst	True Power measurement in	262	0.00
P	True power measurement.	263	0.00
S	Apparent power measurement	264	0.00
PF	Power Factor	265	0.00
Z	Load impedance	266	0.00
HtSinkTemp	Heatsink 1 temperature	269	0.00

Network.Meas - 14 parameters

Figure 6.17.1 Network Meas configuration page

PARAMETERS

This submenu presents power network measurements, according to the network type. All available measurements are listed below, but which values actually appear depends on the network configuration.

Frequency	Displays the calculated frequency of the supply voltage of the power channel associated with this network.
Vline	Supply voltage measurement.
I	Load Irms measurement on primary power module. The time base measurement is the main period in Phase Angle, and the modulation period in Burst Mode.
IsqBurst	Average square value of load current in burst firing. The average Isq in burst firing, the average is taken over the duration of the burst period. This is typically used for monitoring and alarming over the burst period.
Isq	Square value of load current in Burst Firing and over the main period in phase angle.
V	Load Vrms measurement. The time base measurement is the main period in phase angle, and the modulation period in burst mode.
VsqBurst	Average square value of load voltage in burst firing taken over the duration of the burst period. Typically used for monitoring and alarm strategies over the burst period.
Vsq	Square value of load voltage in Burst Firing and on main period in Phase Angle Firing. Typically used for V^2 control.
P Burst	Measurement of true power on the network. This is calculated over the modulation period in Burst Firing mode. Typically used for monitoring and alarm strategy.
P	True power measurement in Burst Firing and over the modulation period in Phase Angle firing. Typically used for true power control.
S	Apparent power measurement. For phase angle firing $S = V_{line} \times I_{RMS}$; for burst firing $S = V_{RMS} \times I_{RMS}$
PF	Calculation of power factor. Defined as Power Factor = True Power / Apparent Power. In phase angle this is $PF = P/S$; in burst firing $PF = PBurst/S = \cos\phi(\text{Load})$
Z	Load impedance measurement on first power module, defined as:- $Z = V_{rms}/I_{rms}$. Measurement uses line current and load voltage
HSink Temp	Reserved for future development.

6.17.2 Network Setup configuration

This displays the setup of the network and associated functions.




Figure 6.17.2 Network setup menu page

PARAMETERS

NetType	The type of network to which the unit can be connected. This is set at the factory and cannot be changed
VMaximum	Indicates the maximum voltage (physical rating) of the stack (500V)
Vline Nominal	Line voltage nominal value (Line to neutral)
IMaximum	Indicates the maximum current of the stack (16A, 25A, 40A, 63A, 100A, 125A). Further values are reserved for future development.
INominal	Nominal current supplied to the load (limited by IMaximum).
VLoadType	Defines the computation method for load voltage (Vload). 0: Vload = Vline as long as $I > I_{threshold}$ (internal definition) 1: Compute Vload using the formula $V^2_{load} = P^2 / I^2$.
VdipsThreshold	Voltage dips threshold. This is a percentage difference (relative to Vline Nominal) between 2 consecutive half cycles. Each half cycle voltage measurement is integrated and at the end of each half cycle the last two voltage integrals are compared.
FreqDriftThold	The supply frequency is checked every half cycle, and if the percentage change between 1/2 cycles exceeds this threshold value, a Mains Frequency System Alarm is generated. The threshold may be set to a maximum of 5% to cater for the effects of heavily inductive networks.
ChopOffThreshold	The 'Chop-off' alarm becomes active if load current exceeds this threshold for more than a pre-defined number of mains periods (Number Chop Off parameter). Threshold values lie between 100% and 400% of the unit's nominal current (INominal).
NumberChopOff	Definition of the number of mains periods in which Chop Off events can occur before a Chop Off alarm is enabled. Only used with Chop Off Threshold.
OverVoltThreshold	The threshold for detecting an over voltage condition as a percentage of VLineNominal. If Vline rises above the threshold an OverVolt alarm is set.
UnderVoltThreshold	This is the threshold for detecting an under voltage condition as a percentage of VLineNominal. If Vline falls below the threshold an UnderVolt alarm is set

6.17.2 NETWORK SETUP CONFIGURATION (Cont.)

PARAMETERS (Cont.)

Heatsink PreTemp	Reserved for future development.
PLFAdjustReq	Partial load failure adjustment request. To make the Partial Load Failure (PLF) alarm operate correctly, the normal steady-state condition must be known to the instrument. This is done by activating the PLF Adjust Req once the controlled process has achieved a steady state condition. This causes a load impedance measurement to be made which is used as a reference for detecting a partial load failure. If the load impedance measurement is successful PLFAdjusted (below) is set. The measurement fails if the load voltage (V) is below 30% of (VNominal) or the current (I) is below 30% of (INominal). The PLF alarm becomes active as setup in 'PLF Sensitivity', below.
PLFAdjusted	Partial load failure adjusted acknowledge. Indicates that the user requested a PLF adjustment and that the adjustment was successful.
PLFSensitivity	Partial load failure sensitivity. This defines how sensitive the partial load failure detection is to be as the ratio between the load impedance for a PLFadjusted load and the current impedance measurement. For example for a load of N parallel, identical elements, if the PLF Sensitivity (s) is set to 2, then a PLF alarm will occur if $N/2$, or more elements are broken (i.e. open circuit). If PLF Sensitivity is set to 3, then a PLF alarm occurs if $N/3$ or more elements are broken. If (N/s) is non-integer, then the sensitivity is rounded up. E.G. if $N = 6$ and $s = 4$, then the alarm is triggered if 2 or more elements are broken.
Zref	Reference load impedance, as measured when PLF adjust is requested.
OverIThreshold	The threshold for detecting an over current condition as a percentage of INominal. If I is above the threshold a Mains Current Alarm occurs (DetoverCurrent).
HeaterType	Shows the type of heater used in the load as: 'Resistive', 'SWIR' (Short wave infra-red), 'CSi' (Silicon Carbide), 'MoSi2' (Molybdenum Disilicide).

6.17. Network alarms




Figure 6.17.3 Network alarms page

ALMDIS

This menu allows individual network block alarms (listed below) to be enabled/disabled. [Section 9](#) gives more details of these alarms

Missing Mains	Mains frequency fault	Total load failure
Thyristor short circuit	Chop Off	Partial load failure
Over temperature	Under voltage	Pre Temperature
Mains voltage (Network) dips	Over voltage	Over current

NETWORK ALMDET SUBMENU

As for 'Alarm Disable', above, but this Alarm detect submenu indicates whether any of the network alarms has been detected and is currently active.

NETWORK ALMSIG SUBMENU

These displays show whether an alarm has occurred and also contains latching information. The relevant AlarmSig parameter is used when wiring (to a relay for example). The alarm list is as given above.

NETWORK ALMLAT SUBMENU

As for 'Alarm Disable', above, but this Alarm Latch submenu allows each individual network block alarm to be defined as latching or non-latching.

NETWORK ALMACK SUBMENU

As for 'Alarm Disable', above, but this Alarm Acknowledge submenu allows each individual network block alarm to be acknowledged. Once acknowledged, the associated signalling parameter is cleared. Acknowledge parameters automatically clear after being written.

Note... Alarms may not be acknowledged whilst the trigger source is still active.

NETWORK ALMSTOP SUBMENU

Allows each individual alarm type to be configured to stop the related power module from firing. Activated by the related Signalling parameter. The alarm list is as given above.

NETWORK ALMRELAY SUBMENU

Allows each individual alarm to be selected to activate (or not) the relay.

6.18 QCODE

Quick code parameters, settable when in Quickcode configuration mode as well as here.




Figure 6.18 Quick code parameters

6.18.1 Parameters

V_Nominal	The nominal output voltage to be supplied.
I_Nominal	The nominal output current expected to be drawn.
Firing	Select firing mode from IHC (Intelligent half cycle), Burst firing (fixed or variable), Logic or Phase angle.
Control	Select 'Vsq' (V^2), 'Isq' (I^2), or 'Power' as the control mode.
I_Limit	Enable or disable threshold limit.
I2_Transfer	Enable or disable transfer (Proportional limit).
XFmr	Select output as suitable for resistive loads (No) or for transformer primary loads (Yes).
Heater	Select Resistive, Short wave infra red (SWIR), Silicon carbide (CSi) or Molybdenum disilicide (MoSi2) as the heating element type.
AI_Fct	Select the Analogue Input function as 'None', 'Setpoint' or 'Setpoint limit'.
AI_Type	Select the required Volt or mA range (as shown above) for the analogue input.
DI1_Fct	Select the function of Digital Input 1 as 'None' or 'Firing Enable'.
DI2_Fct	Select the function of Digital Input 2 as 'None', Alarm acknowledge ('AlarmAck'), Select remote setpoint ('RemoteSelect') or Fuse Blown ('FuseBlown').
Finish	Yes = quit quick code (after confirmation) and restart the unit with the new configuration; No = continue configuration editing; Cancel = ignore all changes and restart the unit with the previous (unedited) configuration.
Refresh	Refresh quick code parameters.

6.19 SETPROV CONFIGURATION MENU

The Setpoint provider supplies one local and one remote setpoint.




Figure 6.19 SetProv configuration page

6.19.1 Setpoint provider parameters

SPSelect	Allows the user to select between Remote or Local as the setpoint source.
RemSelect	Select Remote1 or Remote2 as the remote setpoint.
LocalSP	Allows entry of a setpoint value to be used when SPSelect (above) is set to 'Local'.
Remote1	The Remote setpoint value (normally wired from an analogue input) for use when SPSelect = Remote and RemSelect = Remote1.
Remote2	The Remote setpoint value (normally wired from an analogue input) for use when SPSelect = Remote and RemSelect = Remote2.
Limit	Allows the target setpoint to be scaled such that 'scaled target SP' = (target SP x limit)/100. Thus, when limit = 100, the setpoint is unscaled.
WorkingSP	The active value being provided as a setpoint output. This might be the current target setpoint or the rate-limited target setpoint.
RampRate	This applies a rate limit to the working setpoint, until the target setpoint has been achieved. The 'RateDone' parameter (below) is set to 'No' for the duration of the rate limiting, then set to 'Yes' when rate limiting is complete.
DisRamp	This is an external control used to enable/disable ramp rate limiting and to write the target setpoint directly to the working setpoint. The 'RateDone' parameter (below) is set to 'Yes' when DisRamp is 'Yes'.
RateDone	Set to 'No' if ramp rate limiting (above) is in operation. Otherwise set to 'Yes'.
SPTrack	If enabled ('Yes') the local setpoint tracks the remote setpoints, so that if the setpoint is subsequently set to 'Local', the local setpoint will be the same as the last known value of the remote setpoint, thus ensuring a bumpless transfer.
SPUnits	Allows the user to select % or 'Eng' (Engineering units) as Setpoint units. If 'Eng' is selected, 'HiRange' and 'Eng workingSP' appear at the user interface.
HiRange	Appears only if SP units set to 'Eng'. This value is the high range of the setpoint used to scale the setpoint into % of High Range.
EngWorkingSP	Appears only if SP units set to 'Eng'. This value is an indication of the working setpoint in Engineering units. The parameter must not be used for control because control loops accept setpoints only as % values.

6.20 USER VALUE CONFIGURATION MENU

This provides storage for up to four user-defined constants. Typical uses are as a sources for maths functions, or as storage for values written over the communications link.




Figure 6.20 Top level UseVal page

6.20.1 User Value parameters

- Units** Allows the selection of User value units.
- Resolution** Set the number of decimal places for the User Value value.
- High/Low Limit** Allows the user to set limits to prevent the user value from being set out-of-bounds.
- Value** Allows the user to enter a value, or the value if wired to a suitable parameter.
- Status** If this parameter is wired, it can be used to force a Good or Bad status onto the User Value for test purposes (e.g. fallback strategy).
If not wired, it reflects the status of the Value input if this input is wired.

7 USING ITOOLS

iTools software running on a pc allows quick and easy access to the configuration of the unit. The parameters used are the same as those described in [section 6](#) above, with the addition of various diagnostic parameters. iTools also gives the user the ability to create software wiring between function blocks, something that is not possible from the operator interface. Such wiring is carried out using the Graphical wiring Editor feature. In addition to the guidance given here, there are two on-line Help systems available within iTools: Parameter help and iTools help. Parameter help is accessed by clicking on 'Help' in the toolbar (opens the complete parameter help system), by right-clicking on a parameter and selecting 'Parameter Help' from the resulting context menu, or by clicking on the Help menu and selecting 'Device Help'. iTools help is accessed by clicking on the Help menu, and selecting 'Contents'. iTools help is also available in manual format under part number HA028838, either as a physical manual or as a pdf file.




Figure 7 Help access

7.1 iTools CONNECTION

7.1.1 Automatic detection

The following descriptions assume that the latest version iTools software has been correctly installed on the pc.

For EPack units only (at time of publication), if the desktop/laptop and EPack are IP compatible (same subnet mask) then, Plug & Play allows easy connection as follows.

1. Set correct IP mode and or IP address to the instrument and Personal Computer.
2. Launch iTools, click on the button 'Add' a popup window appears showing you all EPack instruments on the network.
3. Double click on one or more units to add them to iTools.

Note...'Eurotherm discovery' mechanism is based on 'Zero Configuration Networking' which is generic name used to group protocols together in order to create communication networks automatically (Plug & Play)

Alternatively, if there is a mix of EPack and other instruments on the network, the following procedure can be used:

7.1.2 Ethernet (Modbus TCP) communications

*Note...*The following description is based on windows XP. Windows 'Vista' is similar.

It is first necessary to determine the IP address of the unit, as described under 'Comms menu' in section 6.5. This can be done from either the Config or Quickcode menu.

Once the Ethernet link has been correctly installed, carry out the following actions at the pc:

1. Click on 'Start'
2. Click on 'Control Panel'. (If Control Panel opens in 'Category View' select 'Classic View' instead.)
3. Double-click on 'iTools'.

(Continued)

7.1.2 ETHERNET (MODBUS TCP) COMMUNICATIONS (Cont.)

4. Click on the TCP/IP tab in the Registry settings configuration.
5. Click on Add... The 'New TCP/IP Port' dialogue box opens.
6. Type-in a name for the port, then click Add...
7. Type the IP address of the unit in the 'Edit Host' box which appears. Click OK.
8. Check the details in the 'New TCP/IP Port' box, then click on 'OK'.

Click on 'OK' in the 'Registry settings' box to confirm the new port.

)




Figure 7.1.2a Adding a new Ethernet port

7.1.2 ETHERNET (TCP/IP) COMMUNICATIONS (Cont.)

To check that the pc can now communicate with the instrument, Click 'Start'. 'All Programs', 'Accessories', 'Command Prompt'

when the Command Prompt box appears, type in : Ping<Space>IP1.IP2.IP3.IP4<Enter> (where IP1 to IP4 are the IP address of the instrument).

If the Ethernet link to the instrument is operating correctly, the 'successful' reply arrives. Otherwise, the 'failed' reply arrives, in which case, the Ethernet link, IP address, and pc port details should be verified.




Figure 7.1.2b Command prompt 'Ping' screens (typical)

Once the Ethernet link to the instrument has been verified, iTools can be started (or shut down and restarted), and the Scan toolbar icon used, to 'find' the instrument. The scan can be stopped at any time by clicking on the Scan icon a second time.

See [section 7.2](#) for more details of the scan procedure.




7.2 SCANNING FOR INSTRUMENTS

'Clicking on the 'Scan' toolbar icon causes a dialogue box (shown below) to appear. This allows the user to define a search range of addresses.

Notes:

1. Scanning is necessary only when the 'Plug & Play' is not available for the instrument type being searched for.
2. EPack units with software version 2.03 onwards, answer to any request made to their IP addresses independently of any Modbus address setting.
3. The default selection (Scan all device addresses...) will detect any instrument on the serial link, which has a valid address. The 'Scan for Eurotherm devices only' and 'Terminate Scan when first device found' tick boxes can be used to modify the scan process.

As the search progresses, any instruments detected by the scan appear as thumbnails (faceplates) in the 'Panel Views' area, normally located at the bottom of the iTools screen. (options/Panel Views position allows this area to be moved to the top of the window, or the Close icon  can be used to close it. Once closed it can be re-opened by clicking on 'Panel Views' in the 'View' menu.)




Figure 7.2a Scan range enable




Figure 7.2b iTools initial window with one instrument detected

7.3 GRAPHICAL WIRING EDITOR Graphical Wiring

Note... The Graphical wiring editor is a chargeable option, and the toolbar icon appears only if the option has been purchased and is enabled.

Clicking on the Graphical Wiring Editor (GWE) toolbar icon causes the Graphical wiring window for the current instrument configuration to open. Initially, this reflects the preset factory default block wiring..





Figure 7.3 Graphical wiring Editor

The graphical wiring editor allows:

1. Function blocks, notes, comments etc. to be 'drag and dropped' into the wiring diagram from the tree list (left pane).
2. Parameters to be wired to one another by clicking on the output, then clicking on the required input.
3. Viewing and/or editing of parameter values by right-clicking on a function block and selecting 'Function Block View'.
4. The user to select parameter lists and to switch between parameter and wiring editors.
5. Completed wiring to be downloaded to the instrument (function blocks and wiring items with dashed outlines are new, or have been edited since the last download).

7.3.1 Toolbar




Download wiring to Instrument.



Mouse Select. Select normal mouse operation. Mutually exclusive with 'Pan', below.



Mouse Pan. When active, this causes the mouse cursor to become a hand-shaped icon. Allows the graphical wiring diagram to be click-dragged within the GWE window aperture.



Zoom. Allows the magnification of the wiring diagram to be edited.




Pan tool. Whilst left-clicked, the cursor appears as a rectangle, representing the position of GWE window aperture over the whole wiring diagram. Click dragging allows this aperture to be moved freely about the diagram. Rectangle size depends on Zoom (magnification) factor.



Show/Hide grid. This icon toggles a background alignment grid on and off.



Undo, Redo. Allows the user to undo the last action, or once an undo action has taken place, to undo the undo. Short cuts are <Ctrl>+<Z> for undo; <Ctrl>+<R> for re-do.



Cut, Copy, Paste. Normal Cut (copy and delete), Copy (copy without delete) and Paste (insert into) functions. Short cuts are <Ctrl>+<X> for cut; <Ctrl>+<C> for copy and <Ctrl>+<V> for Paste.



Copy diagram fragment; Paste diagram fragment. Allows a part of the wiring diagram to be selected, named and saved to file. The fragment may then be pasted into any wiring diagram, including the source diagram.



Create compound; Flatten compound. These two icons allow compounds to be created and 'uncreated' respectively.

7.3.2 Wiring editor operating details

COMPONENT SELECTION

Single wires are shown with boxes at 'corners' when selected. When more than one wire is selected, as part of a group, the wire colour changes to magenta. All other items have a dashed line drawn round them when selected.

Clicking on a single item selects it. An Item can be added to the selection by holding down the control key (ctrl) whilst clicking on the item. (A selected item can be deselected in the same way.) If a block is selected, then all its associated wires are also selected.

Alternatively, the mouse can be click-dragged on the background to create a 'rubber band' round the relevant area; anything within this area being selected when the mouse is released.

<Ctrl>+<A> selects all items on the active diagram.

BLOCK EXECUTION ORDER

The order in which the blocks are executed by the instrument depends on the way in which they are wired. The order is automatically worked out so that the blocks use the most recent data. Each block displays its place in its sequence in a coloured square in the bottom left-hand corner (figure 7.3.2a).

7.3.2 WIRING EDITOR OPERATING DETAILS (Cont.)

FUNCTION BLOCKS

A Function Block is an algorithm which may be wired to and from other function blocks to make a control strategy. Each function block has inputs and outputs. Any parameter may be wired from, but only parameters that are alterable in Operator Mode may be wired to. A function block includes any parameters that are needed to configure or operate the algorithm. The inputs and outputs which are considered to be of most use are always shown. In most cases all of these need to be wired before the block can perform a useful task.

If a function block is not faded in the tree (left hand pane) it can be dragged onto the diagram. The block can be dragged around the diagram using the mouse.

A Maths block is shown below as an example. When block type information is alterable (as in this case) click on the box with the down arrow in it to display a dialogue box allowing the value to be edited.

If it is required to wire from a parameter, which is not shown as a recommended output, click on the 'Click to Select Output' icon in the bottom right hand corner to display a full list of parameters in the block (figure 7.3.2c, below). Click on one of these to start a wire.




Figure 7.3.2a Function block example

Function Block context menu

Right click in the function block to display the context menu.

Function block View Displays a list of parameters associated with the function block. 'Hidden' parameters can be displayed by de-selecting 'Hide Parameters and Lists when not Relevant' in the Options menu 'Parameter availability Settings...' item.

Re-Route wires Redraws all wiring associated with the function block.

Re-Route Input wires Redraws all Input wiring associated with the function block.

Re-Route Output wires Redraws all Output wiring associated with the function block.

Show Wires Using Tags Wires are not drawn, but their Start and End destinations are indicated by tags instead. Reduces wire 'clutter' in diagrams, where source and destination are widely separated.





Figure 7.3.2b Function block context menu



7.3.2 WIRING EDITOR OPERATING DETAILS (Cont.)

FUNCTION BLOCK CONTEXT MENU (Cont.)

Hide Unwired Connections

Displays only those parameters which are wired.

Cut


Allows one or more selected items to be moved to the Clipboard ready for pasting into another diagram or compound, or for use in a Watch window, or OPC scope. The original items are greyed out, and function blocks and wires are shown dashed until next download, after which they are removed from the diagram. Short cut = <ctrl>+<X>. Cut operations carried out since the last download can be 'undone' by using the 'Undo' toolbar icon, by selecting 'Undelete' or by using the short cut <ctrl>+<Z>.

Copy

Allows one or more selected items to be copied to the Clipboard ready for pasting into another diagram or compound, or for use in a Watch window, or OPC scope. The original items remain in the current wiring diagram. Short cut = <ctrl>+<C>. If items are pasted to the same diagram from which they were copied, the items will be replicated with different block instances. Should this result in more instances of a block than are available, an error display appears showing details of which items couldn't be copied.

Paste

Copies items from the Clipboard to the current wiring diagram. <Ctrl>+<V>. If items are pasted to the same diagram from which they were copied, the items will be replicated with different block instances. Should this result in more instances of a block than are available, a Paste error display appears showing details of which items couldn't be copied.



Delete

Marks all selected items for deletion. Such items are shown dashed until next download, after which they are removed from the diagram. Short cut = .

Undelete

Reverses 'Delete' and 'Cut' operations carried out on selected item(s) since the last download.

Bring To Front

Brings selected items to the front of the diagram.

Push To back

Sends the selected items to the back of the diagram.

Edit Parameter Value...

This menu item is active if the cursor is hovering over an editable parameter. Selecting this menu item causes a pop-up window to appear, which allows the user to edit the parameter value.

Parameter Properties...

This menu item is active if the cursor is hovering over an editable parameter. Selecting this menu item causes a pop-up window to appear, which allows the user to view the parameter properties, and also, to view the parameter Help (by clicking on the 'Help' tab).

Parameter Help...

Produces Parameter Properties and Help information for the selected function block or parameter, depending on the hover position of the cursor, when the right-click occurs.

7.3.2 WIRING EDITOR OPERATING DETAILS (Cont.)

WIRES

To make a wire

1. Drag two (or more) blocks onto the diagram from the function block tree.
2. Start a wire by either clicking on a recommended output or clicking on the 'Click to Select output' icon at the bottom right corner of the block to bring up the connection dialogue, and clicking on the required parameter. Recommended connections are shown with a green plug symbol; other parameters which are available being shown in yellow. Clicking on the red button causes all parameters to be shown. To dismiss the connection dialogue either press the escape key on the keyboard, or click the cross at the bottom left of the dialogue box.
3. Once the wire has started a dashed wire is drawn from the output to the current mouse position. To complete the wire click on the required destination parameter.
4. Wires remain dashed until they are downloaded




Figure 7.3.2c Output selection dialogue box

Routing wires

When a wire is placed it is auto-routed. The auto routing algorithm searches for a clear path between the two blocks. A wire can be auto-routed again using the context menus or by double clicking the wire. A wire segment can be edited manually by click-dragging. If the block to which it is connected is moved, the end of the wire moves with it, retaining as much of the path as possible.

If a wire is selected by clicking on it, it is drawn with small boxes on its corners.

Wire Context Menu

Right click on a wire to display the wire block context menu:

Force Exec Break	When wires form a loop, a break point must be introduced, where the value written to the block comes from a source which was last executed during the previous cycle. A break is automatically placed by iTools, and appears in red. Force Exec Break allows the user to define where a break must be placed. Surplus breaks appear in black.
Re-Route wire	Replaces the current wire route with a new route generated from scratch.
Use Tags	Toggles between wire and tag mode between parameters. Tag mode is useful for sources and destinations which are widely separated.
Find Start	Goes to the source of the wire.
Find End	Goes to the destination of the wire.
Cut, Copy, Paste	Not used in this context.
Delete	Marks the wire for deletion. The wire is redrawn as a dashed line (or dashed tags) until next download. Operation can be reversed until after next download.
Undelete	Reverses the effect of the Delete operation up until the next download, after which, Undelete is disabled.
Bring to Front	Brings the wire to the front of the diagram.
Push to Back	Sends the wire to the back of the diagram.




Figure 7.3.2d
Wire context menu

7.3.2 WIRING EDITOR OPERATING DETAILS (Cont.)

WIRE COLOURS

Black	Normal functioning wire
Red	The wire is connected to a non-changeable parameter. Values are rejected by the destination block.
Magenta	A normal functioning wire is being hovered-over by the mouse cursor.
Purple	A red wire is being hovered-over by the mouse cursor.
Green	New Wire (dashed green wire changes to solid black after being downloaded.)

THICK WIRES

When attempting to wire between blocks which are located in different tasks, if no task break is inserted, then all the affected wires are highlighted by being drawn with a much thicker line than usual. Thick wires still execute, but the results are unpredictable, as the unit cannot resolve the strategy.

COMMENTS

Comments are added to a wiring diagram by click-dragging them from the Function Block tree onto the diagram. As soon as the mouse is released, a dialogue box opens to allow the comment text to be entered. Carriage returns are used to control the width of the comment. Once text entry is complete, 'OK' causes the comment to appear on the diagram. There are no restrictions on the size of a comment. Comments are saved to the instrument along with the diagram layout information.

Comments can be linked to function blocks and wires by clicking on the chain icon at the bottom right-hand corner of the comment box and then clicking again on the required block or wire. A dashed line is drawn to the top of the block or to the selected wire segment (Figure 7.3.2f).

Note: Once the comment has been linked, the Chain icon disappears. It re-appears when the mouse cursor is hovered over the bottom right-hand corner of the comment box, as shown in figure 7.3.2f, below.

Comment Context Menu

Edit	Opens the Comment dialogue box to allow the comment text to be edited.
Unlink	Deletes the current link from the comment.
Cut	Moves the comment to the Clipboard, ready to be pasted elsewhere. Short cut = <ctrl>+<X>.
Copy	Copies the comment from the wiring diagram to the Clipboard, ready to be pasted elsewhere. Short cut = <ctrl>+<C>.
Paste	Copies a comment from the Clipboard to the wiring diagram. Short cut = <ctrl>+<V>.
Delete	Marks the comment for deletion at next download.
Undelete	Undoes the Delete command if download has not taken place since.




Figure 7.3.2e
Comment context
menu

7.3.2 WIRING EDITOR OPERATING DETAILS (Cont.)

MONITORS

Monitor points are added to a wiring diagram by click-dragging them from the Function Block tree onto the diagram. A monitor shows the current value (updated at the iTools parameter list update rate) of the parameter to which it is linked. By default the name of the parameter is shown. To hide the parameter name either double click on the monitor box or 'Show Names' in the context (right-click) menu can be used to toggle the parameter name on and off.

Monitors are linked to function blocks and wires by clicking on the chain icon at the bottom right-hand corner of the box and then clicking again on the required parameter. A dashed line is drawn to the top of the block or the selected wire segment.

Note... Once the monitor has been linked, the Chain icon disappears. It re-appears when the mouse cursor is hovered over the bottom right-hand corner of the monitor box.




Figure 7.3.2f Comment and Monitor appearance

Monitor Context Menu

Show names	Toggles parameter names on and off in the monitor box.
Unlink	Deletes the current link from the monitor.
Cut	Moves the monitor to the Clipboard, ready to be pasted elsewhere. Short cut = <ctrl>+<X>.
Copy	Copies the monitor from the wiring diagram to the Clipboard, ready to be pasted elsewhere. Short cut = <ctrl>+<C>.
Paste	Copies a monitor from the Clipboard to the wiring diagram. Short cut = <ctrl>+<V>.
Delete	Marks the monitor for deletion at next download.
Undelete	Undoes the Delete command if download has not taken place since.
Bring to Front	Moves the item to the 'top' layer of the diagram.
Push to Back	Moves the item to the 'bottom' layer of the diagram.
Parameter Help	Shows parameter help for the item.




Figure 7.3.2g
Monitor context menu

DOWNLOADING

When the wiring editor is opened the current wiring and diagram layout is read from the instrument. No changes are made to the instrument function block execution or wiring until the download button is pressed. Any changes made using the operator interface after the editor is opened are lost on download.

When a block is dropped onto the diagram, instrument parameters are changed to make the parameters for that block available. If changes are made and the editor is closed without saving them there is a delay while the editor clears these parameters.

During download, the wiring is written to the instrument which then calculates the block execution order and starts executing the blocks. The diagram layout including comments and monitors is then written into instrument flash memory along with the current editor settings. When the editor is reopened, the diagram is shown positioned as it was when it was last downloaded.

7.3.2 WIRING EDITOR OPERATING DETAILS (Cont.)

COLOURS

Items on the diagram are coloured as follows:

Red	Items which totally or partially obscure other items and items which are totally or partially obscured by other items. Wires that are connected to unalterable or non-available parameters. Execution breaks. Block execution orders for Task 1.
Blue	Non-available parameters in function blocks. Block execution orders for Task 4. Task breaks.
Green	Items added to the diagram since last download are shown as green dashed lines. Block execution orders for Task 2.
Magenta	All selected items, or any item over which the cursor is hovering.
Purple	Red wires when being hovered over by the mouse cursor.
Black	All items added to the diagram before the last download. Block execution orders for Task 3. Redundant execution breaks. Monitor and comment text.

DIAGRAM CONTEXT MENU

Cut	Active only when the right click occurs within the bounding rectangle which appears when more than one item is selected. Moves the selection off the diagram to the Clipboard. Short cut = <ctrl>+<X>.
Copy	As for 'Cut', but the selection is copied, leaving the original on the diagram. Short cut = <ctrl>+<C>.
Paste	Copies the contents of the Clipboard to the diagram. Short cut = <ctrl>+<V>.
Re-Route wires	Reroutes all selected wires. If no wires are selected, all wires are re-routed.
Align Tops	Aligns the tops of all blocks in the selected area.
Align Lefts	Aligns the left edges of all blocks in the selected area.
Space Evenly	Spaces selected items such that their top left corners are spaced evenly across the width of the diagram. Click on the item which is to be the left-most item, then <ctrl>+<left click> the remaining items in the order in which they are to appear.
Delete	Marks the item for deletion at next download time. Can be 'Undeleted' up until download occurs.
Undelete	Reverses the action of 'Delete' on the selected item.
Select All	Selects all items on the current diagram.
Create Compound	Active only when the right click occurs, in the top level diagram, within the bounding rectangle which appears when more than one item is selected. Creates a new wiring diagram as described in 'Compound', below.
Rename	Allows a new name to entered for the current wiring diagram. This name appears in the relevant tab.
Copy Graphic	Copies the selected items (or the whole diagram if no items are selected) to the clipboard as a Windows metafile, suitable for pasting into a documentation application. Wiring entering/leaving the selection (if any) are drawn in tag mode.
Save Graphic...	As for 'Copy Graphic' above, but saves to a user-specified file location instead of the clipboard.
Copy Fragment To File...	Copies selected items to a user-named file in folder 'My iTools Wiring Fragments' located in 'My Documents'.
Paste Fragment From File	Allows the user to select a stored fragment for inclusion in the wiring diagram.
Centre	Places the display window at the centre of the selected items. If 'Select All' has previously been clicked-on, then the display widow is placed over the centre of the diagram.




Figure 7.3.2h
Diagram context menu

7.3.2 WIRING EDITOR OPERATING DETAILS (Cont.)

COMPOUNDS


Compounds are used to simplify the top level wiring diagram, by allowing the placing of any number of function blocks within one 'box', the inputs and outputs of which operate in the same way as those of a normal function block.

Each time a compound is created, a new tab appears at the top of the wiring diagram. Initially compounds and their tabs are named 'Compound 1', 'Compound 2', etc. but they can be renamed by right clicking either on the compound in the top level diagram, or anywhere within an open Compound, selecting 'Rename' and typing in the required text string (16 characters max.).

Compounds cannot contain other compounds (i.e. they can be created only in the top level diagram).

Compound creation

1. Empty compounds are created within the top level diagram by clicking on the 'Create Compound' toolbar icon.
2. Compounds can also be created by highlighting one or more function blocks in the top level diagram and then clicking on the 'Create Compound' toolbar icon. The highlighted items are moved from the top level diagram into a new compound.
3. Compounds are 'uncreated' (flattened), by highlighting the relevant item in the top level menu and then clicking on the 'Flatten Compound' toolbar icon. All the items previously contained within the compound appear on the top level diagram.
4. Wiring between top level and compound parameters is carried out by clicking on the source parameter, then clicking on the compound (or the compound tab) and then clicking on the destination parameter. Wiring from a compound parameter to a top level parameter or from compound to compound is carried out in similar manner.
5. Unused function blocks can be moved into compounds by dragging from the tree view. Existing blocks can be dragged from the top level diagram, or from another compound, onto the tab associated with the destination compound. Blocks are moved out of compounds to the top level diagram or to another compound in a similar way. Function blocks can also be 'cut and pasted'.
6. Default compound names (e.g. 'Compound 2') are used only once, so that if, for example, Compounds 1 and 2 have been created, and Compound 2 is subsequently deleted, then the next compound to be created will be named 'Compound 3'.
7. Top level elements can be click-dragged into compounds.



7.3.2 WIRING EDITOR OPERATING DETAILS (Cont.)

TOOL TIPS

Hovering the cursor over the block displays 'tooltips' describing that part of the block beneath the cursor. For function block parameters the tooltip shows the parameter description, its OPC name, and, if downloaded, its value. Similar tooltips are shown when hovering over inputs, outputs and over many other items on the iTools screen.

A Function Block is enabled by dragging the block onto the diagram, wiring it, and finally downloading it to the instrument. Initially blocks and associated wires are drawn with dashed lines, and when in this state the parameter list for the block is enabled but the block is not executed by the instrument.


The block is added to the instrument function block execution list when the 'Download' icon is operated and the items are redrawn using solid lines.

If a block which has been downloaded is deleted, it is shown on the diagram in a ghosted form until the download button is pressed. (This is because it and any wires to/from it are still being executed in the instrument. On download it will be removed from the instrument execution list and the diagram.) A ghosted block can be 'undeleted' as described in 'Context menu', above.

When a dashed block is deleted it is removed immediately.

7.4 PARAMETER EXPLORER

This view is displayed:

1. by clicking on the 'Parameter Explorer' toolbar icon,  Parameter Explorer
2. by double clicking on the relevant block in the tree pane or in the graphical wiring editor
3. by selecting 'Function Block View' from the Function block context menu in the Graphical wiring Editor.
4. by selecting 'parameter Explorer' from the 'View' menu
5. by using the short cut <Alt>+<Enter>

In each case the function block parameters appear in the iTools window in tabular form, such as the example in figure 7.4a, below.




Figure 7.4a Parameter table example

The figure above shows the default table layout. Columns can be added/deleted from the view using the 'Columns' item of the Explorer or context menus (figure 7.4b).

7.4 PARAMETER EXPLORER (Cont.)



Figure 7.4b Column enable/disable

Figure 7.4.1 Parameter explorer detail

Figure 7.4.1a shows a typical parameter table. This particular parameter has a number of subfolders associated with it, and each of these is represented by a 'tab' across the top of the table.

Name	Description	Address	Value	Low Limit	High Limit
Frequency	Frequency of the line	267	0.00	-10000000000.00	10000000000.00
Vline	Line voltage measurement	256	0.00	-10000000000.00	10000000000.00
I	Irms of the load	257	0.00	-10000000000.00	10000000000.00
IsqBurst	Average square value of load	258	0.00	-10000000000.00	10000000000.00
Isq	Square value of the load current	259	0.00	-10000000000.00	10000000000.00
V	Vrms of the load	260	0.00	-10000000000.00	10000000000.00
VsqBurst	Average square value of the	268	0.00	-10000000000.00	10000000000.00
Vsq	Square value of load voltage	261	0.00	-10000000000.00	10000000000.00
PBurst	True Power measurement in	262	0.00	-10000000000.00	10000000000.00
P	True power measurement.	263	0.00	-10000000000.00	10000000000.00
S	Apparent power measurement	264	0.00	-10000000000.00	10000000000.00
PF	Power Factor	265	0.00	-10000000000.00	10000000000.00
Z	Load impedance	266	0.00	-10000000000.00	10000000000.00
HtSinkTemp	Heatsink 1 temperature	269	0.00	-10000000000.00	10000000000.00

Network.Meas - 14 parameters

Figure 7.4.1a Typical parameter table

Notes:

- Parameters in blue are non-editable (Read only). In the example above all the parameters are read only. Read/write parameters are in black and have a 'pencil' symbol in the 'read/write access' column at the left edge of the table. A number of such items are shown in figure 7.4a, above.
- Columns. The default explorer window (figure 7.4a) contains the columns 'Name', 'Description', 'Address' and 'Value'. As can be seen from figure 7.4b, above, the columns to be displayed can be selected, to a certain extent, using either the 'Explorer' menu or the context menu. 'Limits' have been enabled for the example above.
- Hidden Parameters. By default, iTools hides parameters which are considered irrelevant in the current context. Such hidden parameters can be shown in the table using the 'Parameter availability' settings item of the options menu (figure 7.4.1b). Such items are displayed with a shaded background.
- The full pathname for the displayed parameter list is shown at the bottom left hand corner of the window.

7.4.1 PARAMETER EXPLORER DETAIL (Cont.)




Figure 7.4.1b Show/Hide parameters

7.4.2 Explorer tools

A number of tool icons appear above the parameter list:


Back to: and Forward to:. The parameter explorer contains a history buffer of up to 10 lists that have been browsed in the current instance of the window. The 'Back to: (list name)' and 'Forward to: (list name)' icons allow easy retracing or repeating of the parameter list view sequence.

If the mouse cursor is hovered over the tool icon, the name of the parameter list which will appear if the icon is clicked-on appears. Clicking on the arrow head displays a pick list of up to 10 previously visited lists which the user can select. Short cut = <ctrl>+ for 'Back to' or <ctrl>+<F> for 'Forward to'.

Go Up a Level, Go Down a Level. For nested parameters, these buttons allow the user to navigate 'vertically' between levels. Short cut = <ctrl>+<U> for 'Go Up a Level' or <ctrl>+<D> for 'Go Down a Level'.

Push pin to give the window global scope. Clicking on this icon causes the current parameter list to be permanently displayed, even if another instrument becomes the 'current device'.

7.4.3 Context Menu



Copy Parameter
Parameter properties
Parameter Help...
Columns

Copies the clicked-on parameter to the clipboard
Displays parameter properties for the clicked-on parameter
Displays help information for the clicked-on parameter
Allows the user to enable/disable a number of parameter table columns ([figure 7.4b](#)).

7.5 FIELDBUS GATEWAY Fieldbus I/O Gateway

EPack controller units contain a great number of parameters, so it is necessary for the user to define which Input and Output parameters are to be available for block read and write. The Input/Output definitions are configured using the 'Fieldbus I/O Gateway'.




Figure 7.5a Typical Fieldbus Gateway Parameter list

As shown in figure 7.5a, above, there are two tabs within the editor, called 'Input definition' and 'Output definition'. 'Inputs' are values sent from the controller to the Profibus master. 'Outputs' are values received from the master and used by the controller, (e.g. set points written from the master).

The procedure for selecting variables is the same for both input and output definition tabs:

1. Double click the next available position in the input or output data table and select the variable to assign to it. A pop-up (figure 7.5b) provides a browser from which a list of parameters can be opened.
2. Double click the parameter to assign it to the input definition.




Figure 7.5b Browser window

Notes:

1. By setting the same parameter contiguously (e.g. main.sp for inputs 2 and 3) the data will be sent in IEEE format.
2. The Master must request the same number of parameters as there are in the table.
3. The tables are saved to Flash memory when the user quits configuration mode and returns to Operator mode.


7.5 FIELDBUS GATEWAY(Cont.)

When all the required parameters have been added to the lists, notes of how many 'wired' entries are included in the input and output areas should be made as this information is needed when setting up the Master.

Notes:

1. A maximum of 32 input and 16 output parameters may be set using the Gateway Editor.
2. No checks are made that output variables are writeable, and if a read only variable is included in the output list any values sent to it will be ignored with no error indication.
3. For Modbus only:

As shown in figure 7.5c, 'Block Read' and 'Block Write' requests both access the same memory location (Dec:4744; hex:1288), which 'points' to the relevant input definition table or output definition table according to whether the instruction is a read or a write. The value for a parameter in the input table may differ from the value of the same parameter in the output table.

Once the changes have been made to the Input and Output definition lists, they must be downloaded to the controller unit. This is done (for both tables simultaneously) by clicking on the 'Update device Flash Memory' button on the top left of the Fieldbus Gateway Editor window. The controller performs a restart after this operation. 




Figure 7.5c Block read and block write (note 3)

7.6 WATCH/RECIPE EDITOR Watch/Recipe

The watch/recipe editor is opened by clicking on the Watch/Recipe tool icon, by selecting 'Watch/Recipe' in the 'Views' menu or by using the short cut <ctrl>+<A>. The window is in two parts: the left part containing the watch list; the right-hand part containing one or more data sets, initially empty and unnamed.

The Watch/Recipe window is used:

1. To monitor a list of parameters. This list can contain parameters from many different, and otherwise unrelated parameter lists within the same device. It cannot contain parameters from different devices.
2. To create 'data sets' of parameter values which can be selected and downloaded to the device in the sequence defined in the recipe. The same parameter may be used more than once in a recipe.





Figure 7.6 Watch/Recipe Editor window (with context menu)

7.6.1 Creating a Watch List


After opening the window, parameters can be added to it as described below. The values of the parameters update in real-time, allowing the user to monitor a number of values simultaneously.

ADDING PARAMETERS TO THE WATCH LIST

1. Parameters can be click-dragged into the watch list from another area of the iTools window (for example, the parameter explorer window, the graphical wiring editor, the browse tree). The parameter is placed either in an empty row at the bottom of the list, or if it is dragged on top of an already existing parameter, it is inserted above this parameter, with the remaining parameters being moved down one place.
2. Parameters can be dragged from one position in the list to another. In such a case, a copy of the parameter is produced, the source parameter remaining in its original position.
3. Parameters can be copied <ctrl>+<C> and pasted <ctrl>+<V> either within the list, or from a source external to it, for example the parameter browse window or the graphical wiring editor.
4. The 'Insert item...' tool button  the 'Insert Parameter' item in the Recipe or context menu or the short cut <Insert> can be used to open a browse window from which a parameter is selected for insertion above the currently selected parameter.

DATA SET CREATION

Once all the required parameters have been added to the list, select the empty data set by clicking on the column header. Fill the data set with current values using one of the following methods:

1. Clicking on the 'Capture current values into a data set' tool icon  (also known as the 'Snapshot Values' tool).
2. Selecting 'Snapshot Values' from the Recipe or Context (right-click) menu.
3. Using the short cut <ctrl>+<A>.


7.6.1 CREATING A WATCH LIST (Cont.)

DATA SET CREATION (Cont.)


Individual data values can now be edited by typing directly into the grid cells. Data values can be left blank or cleared, in which case, no values will be written for those parameters at download. Data values are cleared by deleting all the characters in the cell then either moving to a different cell or typing <Enter>.

The set is called 'Set 1' by default, but it can be renamed by either by using the 'Rename data set...' item in the Recipe or context menus, or by using the short cut <ctrl>+<R>.













New, empty data sets can be added using one of the following:

1. Clicking on the 'Create a new empty data set' toolbar icon. 
2. Selecting 'New Data Set' in the Recipe or context menus
3. Using the short cut <ctrl>+<W>

Once created, the data sets are edited as described above.

Finally, once all the required data sets have been created, edited and saved, they can be downloaded the instrument, one at a time, using the Download tool, the 'Download Values' item in the Recipe or context menus, or the short cut <ctrl>+<D>. 

7.6.2 Watch Recipe toolbar icons

-  Create a new watch/recipe list. Creates a new list by clearing out all parameters and data sets from an open window. If the current list has not been saved, confirmation is requested. Short cut <ctrl>+<N>
-  Open an existing watch/recipe file. If the current list or data set has not been saved, confirmation is requested. A file dialogue box then opens allowing the user to select a file to be opened. Short cut <ctrl>+<O>
-  Save the current watch/recipe list. Allows the current set to be saved to a user specified location. Short cut <ctrl>+<S>.
-  Download the selected data set to the device. Short cut <ctrl>+<D>
-  Insert item ahead of selected item. Short cut <Insert>.
-  Remove recipe parameter. Short cut <ctrl>+<Delete>.
-  Move selected item. Up arrow moves selected parameter up the list; down arrow move the selected parameter down the list.
-  Create a new empty data set. Short cut <ctrl>+<w>.
-  Delete an empty data set. Short cut <ctrl>+<Delete>
-  Capture current values into a data set. Fills the selected data set with values. Short cut <ctrl>+<A>.
-  Clear the selected data set. Removes values from the selected data set. Short cut <Shift>+<Delete>.
-  Open OPC Scope. Opens a separate utility that allows trending, data logging and Dynamic Data Exchange (DDE). OPC Scope is an OPC explorer program that can connect to any OPC server that is in the windows registry. (OPC is an acronym for 'OLE for Process Control, where OLE stands for 'Object Linking and Embedding'.)

7.6.3 Watch/Recipe Context Menu

The Watch/Recipe Context menu items have the same functions as described above for toolbar items.

8 PARAMETER ADDRESSES (MODBUS)

8.1 INTRODUCTION

The iTools address fields display each parameter's Modbus address to be used when addressing integer values over the serial communications link. In order to access these values as IEEE floating point values, the calculation: IEEE address = {(Modbus address x 2) + hex 8000} should be used.

Notes:

1. Certain parameters may have values which exceed the maximum value that can be read from or written to using a 16-bit integer communications. Such parameters have a scaling factor applied to them as described in section 8.3.
 2. When using 16-bit scaled integer modbus addressing, time parameters can be read from or written to in 10ths of minutes, or in 10ths of seconds as defined in the parameter [Instrument.config.TimerRes](#).
-

8.2 PARAMETER TYPES

The following parameter types are used:

bool	Boolean
uint8	Unsigned 8-bit integer
int16	Signed 16-bit integer
uint16	Unsigned 16-bit integer
int32	Signed 32-bit integer
uint32	Unsigned 32-bit integer
time32	Unsigned 32-bit integer (time in milliseconds)
float32	IEEE 32-bit floating point
string	String - an array of unsigned 8-bit integers.

8.3 PARAMETER SCALING

Some parameters might have values which exceed the maximum value (32767) that can be read/written via 16-bit scaled integer comms. Such parameters are assigned a scaling factor as described in [section 6.11.4](#).

8.4 PARAMETER LIST

The full list of parameters available via the communications link is to be found the the SCADA table supplied as a part of the iTools help system. Individual parameter addresses also appear in each iTools configuration page along with 'enumerations' showing all the possible values that the parameter can take).

9 ALARMS

9.1 SYSTEM ALARMS

System alarms are considered to be 'Major Events' which prevent proper operation of the system, and the unit is placed in standby mode.

The following subsections describe each of the possible system alarms.

9.1.1 Missing mains

Supply power is missing.

9.1.2 Thyristor short circuit

A thyristor short circuit leads to current flow even when not firing.

9.1.3 Thyristor open circuit

This fault means that no current flow occurs, even when the thyristor(s) should be firing.

9.1.4 Over temperature

Reserved for future development.

9.1.5 Network dips

This detects a reduction in supply voltage, and if this reduction exceeds a configurable measured value (VdipsThreshold), firing will be inhibited until the supply voltage returns to a suitable value. VdipsThreshold represents a percentage change in supply voltage between successive half cycles, and can be defined by the user in the Network.Setup menu, as described in [section 6.17.2](#).

9.1.6 Mains frequency fault

Triggered if the supply voltage frequency strays out of the range 47 to 63 Hz, or if the mains frequency changes, for one cycle to the next, by more than the threshold defined in the Network.Setup menu described in [section 6.17.2](#)

The value can be adjusted between 0.9% and 5%, the default value is 2%.

9.1.7 Chop Off alarm

Chop-off alarm will be active when a current threshold is exceeded for more than a pre-defined number of mains periods. This current threshold is user-adjustable from 100% to 400% of unit's nominal current. (to be found in the Network.setup area of configuration ([section 6.17.2](#))).

9.2 PROCESS ALARMS

Process Alarms are related to the application and can be configured either to stop the unit firing (Standby Mode) or to allow operation to continue. Process alarms can also be configured to be latched and if so, they have to be acknowledged before the alarm is considered to be non-active. Alarms cannot be acknowledged until the trigger source has returned to a non-active state.

9.2.1 Total Load Failure (TLF)

No load is connected.

9.2.2 Closed Loop alarm

Closed loop break alarm is currently active.

9.2.3 Alarm input

The alarm input associated with the alarm block is active.

9.2.4 Over current detection

The analogue input over current detection alarm is active.

9.2.5 OverVoltage Alarm

An 'OverVoltThreshold' can be configured in the Network.Setup area of configuration ([section 6.17.2](#)) as a percentage of VLineNominal. If the VLine voltage rises above this threshold the OverVoltage alarm is set.

Note...This Alarm is returned FALSE if the MissingMains Alarm is set.

9.2.6 UnderVoltage Alarm

An 'UnderVoltThreshold' can be configured in the Network.Setup area of configuration ([section 6.17.2](#)) as a percentage of VLineNominal. If the VLine voltage falls below this threshold the UnderVoltage alarm is set.

Note...This Alarm is returned FALSE if the MissingMains Alarm is set.

9.2.7 Partial Load Failure (PLF)

This alarm detects a static increase in load impedance by comparing the reference load impedance (as configured by the user) with the actual measured load impedance over a mains cycle (for phase angle firing) and over the burst period (for burst and logic firing).

The sensitivity of the partial load failure measurement can be set to any value between 2 to 6 inclusive, where an entry of 2, for example, means that one half of the elements (or more) must be open circuit in order to trigger the alarm; an entry of 3 means that one third of the elements (or more) must be open circuit in order to trigger the alarm, and so on down to one sixth. All elements must have identical characteristics and identical impedance values and must be connected in parallel).

The relevant parameters (PLFAdjustReq, and PLFSensitivity) are both to be found in Network.Setup, as described in [section 6.17.2](#).

9.3 INDICATION ALARMS

Indication Alarms signal events for operator action if required. Indication alarms cannot be configured to stop power module firing, but they may be latched if required, and if latched, they must be acknowledged for the Signaling Status to return to the normal (non-alarm) state.

9.3.1 Process Value Transfer active

Indicates when a transfer control mode (e.g. $V^2 <> I^2$ P $<> I^2$ or $V^2 <> I^2$) is active.

9.3.2 Limitation active

Indicates when the internal firing control loop limits the firing output (I^2 or V^2) (in order not to exceed the adjusted maximum value)

9.3.3 Load Over-Current

Indicates when a configurable RMS load current threshold (Overlthreshold) is reached or exceeded. The parameter is found in the Network.Setup area of configuration ([section 6.17.2](#)) and is configurable as 10% to 400% of Nominal Current.

10 MAINTENANCE

10.1 SAFETY

WARNING

BRANCH-CIRCUIT PROTECTION AND SAFETY OVERLOAD PROTECTION

This product does not contain any branch-circuit protection or internal safety overload protection. It is the responsibility of the user to add branch-circuit protection upstream of the unit. It is also the responsibility of the user to provide external or remote safety overload protection to the end installation. Such branch-circuit and safety overload protection must comply with applicable local regulations.

UL: The abovementioned branch-circuit protection is necessary for compliance with National Electric Code (NEC) requirements.

WARNINGS

1. The manufacturer shall not be held responsible for any damage, injury, losses or expenses caused by inappropriate use of the product or by failure to comply with the instructions in this manual. It is the responsibility of the user to check, before commissioning the unit, that all nominal characteristics correspond to the conditions under which it is to be installed and used.
 2. The product must be commissioned and maintained by suitably qualified personnel, authorized to work in an industrial low voltage environment.
 3. Voltage of over 500V RMS may exist in and around the units, even when they are not 'running'. Ensure that all sources of hazardous voltages are isolated from the units before carrying out any work on the units.
 4. The heat sink becomes hot whilst the unit is running, and it can take up to 15 minutes to cool after the unit is shut down. Touching the heat sink, even briefly, must be avoided whilst the unit is operating.
-

10.2 PREVENTIVE MAINTENANCE

Please read the warnings above, before attempting to carry out any work on the unit(s).

1. Every six months check that all power and protective earth cable connections are correctly tightened ([Section 2.2.1](#)). This check should include the safety earth connections to the cabinet.
2. To maintain maximum cooling efficiency, the Power Module heat-sink must be cleaned regularly. Periodicity depends on the local environment, but should not exceed six months.

10.3 FUSING

According to the CE and UL certifications, high speed fuses are mandatory for the protection of the EPack power controller against short circuit.

The power circuit shall be protected by a supplementary fuse as described in the table 10.3a below. These should be used in conjunction with suitable fuse holders and contact kits (if required) as shown in the table 10.3b. The coloured areas indicate which fuses use which fuse holders

With a supplementary fuse (high speed fuse), EPack is suitable for use on a circuit capable of delivering not more than 100kA RMS symmetrical amperes, 500 Volts Maximum. (coordination Type 1)

WARNING

If either the branch circuit protective or the supplementary fuse (high speed fuse) ruptures, supply voltages shall be isolated and the EPack unit examined and replaced if damaged.

		Fuse body size (mm)		Invensys part number	
EPack nominal current	Fuse rating	Without blown fuse indicator	With blown fuse indicator	Without blown fuse indicator	With blown fuse indicator
≤25A	32A	10 x 38	14 x 51	CS031505U002	CS031506U002
32A	40A	14 x 51	14 x 51	CS031507U002	CS031508U002
40A	50A	14 x 51	14 x 51	CS031509U002	CS031510U002
50A	63A	22 x 58	22 x 58	CS031511U002	CS031512U002
63A	80A	27 x 60	27 x 60		CS031513U002
80A	200A	27 x 60	27 x 60		CS032166U002
100A	200A	27 x 60	27 x 60		CS032166U002
125A	200A	27 x 60	27 x 60		CS032166U002

Table 10.3a Fuse details

Fuse part number (Invensys)	Fuse holder part no. (Invensys)	Contact kit part no. (Invensys)	Blown fuse indication
CS031505U002	CP018525		No
CS031506U002	CP171480	CP177220	Yes
CS031507U002	CP171480		No
CS031508U002	CP171480	CP177220	Yes
CS031509U002	CP171480		No
CS031510U002	CP171480	CP177220	Yes
CS031511U002	CP173083		No
CS031512U002	CP173083	CP177221	Yes
CS031513U002	CP173245		No
CS031513U002	CP173245	CP177222	Yes
CS032166U002	CP173245		No
CS032166U002	CP173245	CP177222	Yes

Table 10.3b Fuse holders and contact kits

10.3.1 Fuse dimensions

Figures 10.3.1a to 10.3.1d show dimensional details for a number of common fuses (not all shown to the same scale).




Figure 10.3.1a Fuse dimensions: US10




Figure 10.3.1b Fuse dimensions: US14

10.3.1 FUSE DIMENSIONS (Cont.)




Figure 10.3.1c Fuse dimensions: US22




Figure 10.3.1d Fuse dimensions: US27

10.4 INSTRUMENT UPGRADE

Instrument upgrade is done in three steps: upgrading iTools to the latest version, upgrading firmware and upgrading software.

10.4.1 iTools upgrade

Locate the 'Downloads' section of the www.Eurotherm.com website, and select iTools Software from the Software list. Click on 'DOWNLOAD' and follow the instructions.




Figure 10.4.1 Downloads section

10.4.2 Firmware upgrade

With the relevant instrument selected in iTools, click on the Help menu and select 'Check for Updates...'. Click on 'Firmware upgrade' and follow the instructions.




Figure 10.4.2 Check for updates

10.4.3 Software upgrade

Software upgrade can be carried out by one of two methods, as follows:

OBTAINING A PASSCODE VIA TELEPHONE

1. Telephone the local Eurotherm Sales/Service agent with the Serial number of the instrument to be updated, and the current software version. The serial number is to be found on the side label of the instrument; the software version at the bottom of the iTools window, as shown.
2. Place an order for the required new functionality.
3. A new passcode will be provided which is to be entered in the Instrument Options configuration.





Figure 10.4.3a Instrument options configuration

OBTAINING A PASSCODE VIA ITOOLS

1. Click on the 'iTools Secure' toolbutton
2. Accept the warning
3. Select the functions required from the displayed list (figure 10.4.3b)
4. Click on 'Proceed...'. This sends an email requesting the option passcode. Follow the instructions.
5. Enter the new passcode as described in step three above.




Figure 10.4.3b iTools secure

EPACK LICENCE NOTICE

FreeRTOS

Epack is powered by an original FreeRTOS from version v7.1.0 .

FreeRTOS is available at <http://www.freertos.org>

microutf8

/* microutf8.c

Copyright (C) 2011 by Tomasz Konojacki

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

*/

lwip

/*

* Copyright (c) 2001, 2002 Swedish Institute of Computer Science.

* All rights reserved.

*

* Redistribution and use in source and binary forms, with or without modification,

* are permitted provided that the following conditions are met:

*

* 1. Redistributions of source code must retain the above copyright notice,

* this list of conditions and the following disclaimer.

* 2. Redistributions in binary form must reproduce the above copyright notice,

* this list of conditions and the following disclaimer in the documentation

* and/or other materials provided with the distribution.

* 3. The name of the author may not be used to endorse or promote products

* derived from this software without specific prior written permission.

*

This page is deliberately left blank

Appendix A: TECHNICAL SPECIFICATION

A1 STANDARDS

STANDARDS

The product is designed and produced to comply with EN60947-4-3 (Low voltage switch gear and control gear) and with UL60947-4-1 and CAN/CSA C22.2 . Other applicable standards are cited where appropriate.

INSTALLATION CATEGORIES

General installation category details for the driver and power modules are summarized in the table below.

	Installation Category	Rated impulse withstand voltage (Uimp)	Rated insulation voltage
Communications	II	0.5 kV	50 V
Standard IO	II	0.5 kV	50 V
Relays	II	2.5 kV	230 V
Unit Power	III	6 kV	500 V

Table A1 Installation categories

A2 SPECIFICATION

POWER (at 45°C)

Voltage range	Load: 100 to 500V (+10% -15%) Auxiliary: 24V ac/dc (+20% -20%) or 100 to 500V (+10% -15%) 47 to 63 Hz for line and ac auxiliary supplies)	<div style="border: 1px solid black; padding: 5px; text-align: center;"> WARNING For 24V supplies, in order to comply with safety requirements, the supply voltage must be derived from a SELV or PELV circuit. </div>
Frequency range		
Power requirement	24V dc 12W 24V ac 18VA 500V ac 20VA	
Installation category	See table A1 above.	
Nominal load current	16 to 125 Amps	
Rated short-circuit conditional current	100kA (coordination type 1). See section 10.3 (fusing)	
Pollution degree	Pollution degree 2	
Utilization categories (Load types)	AC51: Non-inductive or slightly inductive loads, resistance furnaces AC56a: Transformer Primary or MOSI (Molybdenum Silicide) Time temperature dependant loads (Silicon Carbide, Carbon)	
Duty cycle	Uninterrupted duty / continuous operation	
Short circuit protection	None within the unit	
Load Types	Single phase control of resistive loads (low/high temperature coefficient and non-aging/aging types) and transformer primaries.	
Overload conditions	AC51: 1xle continuous.	

PHYSICAL

Dimensions and fixing centres	See figures 2.2.1b , 2.2.1c , 2.2.1d and 2.2.1e for details
Weight	16 to 32A units 800g + user connectors 40 to 63A units 950g + user connectors 80A and 100A units 1800g + user connectos 125 A units 2500g + user connectors

ENVIRONMENT

Temperature limits	Operating: 0°C to 45°C Storage: -25°C to +70°C
Humidity limits	5% to 95% RH (non-condensing)
Altitude	1000 metres maximum at 45 degrees.
Protection (CE)	32A and 63A units: IP10 (EN60529) 80A, 100A and 125A units: IP20 (EN60529)*
Protection (UL)	All units: Open type
Atmosphere	Non-explosive, non-corrosive, non-conductive
External wiring	General: Must comply with IEC60364-1 and IEC60364-5-54 and all applicable local regulations. Cross sections must comply with Table 9 of IEC60947-1. UL: Wiring must comply with NEC and all applicable local regulations. Cross sections must comply with NEC, Article 310 Table 310-16.(see Table 2.2.1 of this manual for temperature ratings) To (EN60068-2-27) and IEC60947-1 Annex Q To (EN60068-2-6) and IEC60947-1 Annex Q
Shock	
Vibration (EN60068-2-6)*	

*In order to maintain IP20 rating, the wiring and installation requirements defined in [section 2.2.2](#) must be adhered to.

A2 SPECIFICATION (Cont.)

EMC

Standard

EN60947-4-3:2000 (2000-01-12), EN60947-4-3:2000/A1:2006 (2006-12-08), EN60947-4-3:2000/A2:2011 (2011-09-02)
 This product has been designed for environment A (Industrial). Use of this product in environment B (domestic, commercial and light industrial) may cause unwanted electromagnetic disturbances in which cases the user may be required to take adequate mitigation measures.
 See table A2a

Test Results

Note: In common with the rest of the industry, in phase angle operation, conducted emissions to the line can meet the requirements of IEC60947-4-3 only if an external filter is fitted in the line connection.

EMC Immunity tests	Level		Criteria	
	Requested	Achieved	Requested	Achieved
Electrostatic discharge (test method given in IEC 61000-4-2)	Air discharge mode 8kV Contact discharge mode 4kV	Air discharge mode 8kV Contact discharge mode 4kV	2	1
Radio frequency voltage immunity (test method according to IEC 61000-4-6)	10V (140dB/μV) from 0.15MHz to 80MHz	10V (140dB/μV) from 0.15MHz to 80MHz	1	1
Electromagnetic radiated immunity (test method IEC 61000-4-3)	10V/m from 80MHz to 1GHz	12V/m from 80MHz to 3GHz	1	1
Fast transients test (5/50ns) (test method IEC 61000-4-4)	Power line, auxiliary circuit and control 2kV/5kHz	Power line, auxiliary circuit and control 2.2kV/5kHz	2	2
Surge voltage immunity test (1.2/50μs - 8/20μs) (test method IEC 61000-4-5)	2kV line to earth 1kV line to line	2kV line to earth 1kV line to line	2	2
Voltage dips and short time interruptions immunity (test method IEC 61000-4-11)*	5000ms at 0%	5000ms at 0%	3	3

Table A2a1 EMC immunity tests

Type	Dips/interruption	Number of cycles	Criteria	
			Requested	Achieved
Voltage dips immunity	0%	0.5 cycle and 1 cycle	2	2
	40%	10/12 cycles	3	3
	70%	25/30 cycles	3	2
	80%	250/300 cycles	3	2
Short time interruptions immunity	0%	250/300 cycles	3	2

Table A2a2 Voltage dips and short term interruptions tests

EMC Emissions test	Frequency (MHz)	Level for class A industrial	
		Quasi peak dB (μV)	Average
Electromagnetic Radiated Emissions (test method CISPR11)	30 to 230	50 at 3m	/
	230 to 1000	57 at 3m	/
Conducted emissions (test method CISPR11)	0.15 to 0.5	100	90

Table A2a3 EMC Emissions tests

*Voltage Dips and short time interruptions immunity (test method of EN 61000-4-11) requested by IEC 60947-4-3 issue 2.0 of 05/2014. (Publication due date: 03 /2015).

A2 SPECIFICATION (Cont.)

OPERATOR INTERFACE

Display	1.5" square TFT colour display allowing viewing of selected parameter values in real time, plus configuration of instrument parameters for users with adequate access permission.
Pushbuttons	Four push buttons provide page and item entry and scroll facilities.

INPUTS/OUTPUTS

All figures are with respect to 0V, unless otherwise stated.

Number of inputs/outputs	1 Analogue input; 2 Digital inputs; 1 Relay output
Update rate	Twice the mains frequency. Defaults to 55 Hz (18 ms) if the supply frequency lies outside the range 47 to 63 Hz.)
Termination	Removable 5-way connector. (5.08 mm. pitch) located as shown in figure 2.2.3 .

ANALOGUE INPUT

Performance	See tables A2band A2c
Input type	Configurable as one of: 0 to 10V, 1 to 5V, 2 to 10V, 0 to 5V, 0 to 20mA, 4 to 20mA
Absolute input maxima	±16V or ±40mA

Analogue input: Voltage input performance		
Parameter	Typical	Max/Min
Total voltage working input span		0V to +10V
Resolution (noise free) (note 1)	11 bits	
Calibration error (notes 2, 3)	<0.1%	<0.1%
Linearity error (note 2)		±0.1%
Ambient temperature error (note 3)		<0.01%/°C
Input resistance (terminal to 0V)	142kΩ	±0.2%
Note 1: w.r.t. total working span Note 3: After warm up. Ambient = 25 °C		
Note 2: % of effective range (0 to 5V, 0 to 10V)		

Table A2a Analogue input specification (voltage inputs)

Analogue input: Current input performance		
Parameter	Typical	Max/Min
Total current working input span		0 to +25mA
Resolution (noise free) (note 1)	11 bits	
Calibration error (notes 2, 3)		<0.2%
Linearity error (note 2)		±0.1%
Ambient temperature error (note 2)		±0.01%/°C
Input resistance (terminal to 0V)	<102Ω	±1%
Note 1: w.r.t. total working span Note 3: After warm up. Ambient = 25 °C		
Note 2: % of effective range (0 to 20mA)		

Table A2c Analogue input specification (current inputs)

A2 SPECIFICATION (Cont.)

DIGITAL INPUTS

Voltage inputs	
Active level (high)	4.4V < V_{in} < 30V
Non-active level (low)	-30V < V_{in} < +2.3V
Input impedance:	27k Ω (typ.) for voltage input mode
Contact closure inputs	
Source current:	10mA min; 15mA max
Open contact (non active) resistance:	>500 Ω
Closed contact (active) resistance:	<150 Ω
Absolute Maxima	$\pm 30V$ or $\pm 25mA$

Notes:

- 1 Absolute maximum ratings refer to externally applied signals.
- 2 PLC compatibility : Digital inputs are not 100% compliant with IEC 61131-2 (It is recommended that the user check compatibility before use.)

RELAY SPECIFICATION

The relay has gold plated contacts suitable for 'dry circuit' (low current) use. Pinout given in [figure 2.2.3](#).

Contact life	Resistive loads:	100,000 operations
	Inductive loads:	Derate as per accompanying graph (figure A2)
High power use	Current:	2A (resistive loads)
	Voltage:	<264V RMS (UL: voltage 250Vac.)
Low power use	Current:	>1mA
	Voltage:	>1V
Contact configuration	Single pole change-over (one set of Common, Normally Open and Normally Closed contacts)	
Termination	Removable 3-way connector. (5.08 mm. pitch) located as shown in figure 2.2.3 .	
Installation Category	Installation category III, assuming that nominal phase to earth voltage is $\leq 300V$ RMS.	
Absolute max. switching capability	<2A at 240V RMS (resistive loads)	

Note... 'Normally Closed' and 'Normally Open' refer to the relay when the coil is not energised.




Figure A2 Relay derating curves

A2 SPECIFICATION (Cont.)

MAINS NETWORK MEASUREMENTS

All network measurements are calculated over a full mains cycle, but internally updated every half-cycle. For this reason, power control, current limits and alarms all run at the mains half-cycle rate. The calculations are based on waveform samples taken at a rate of 20kHz. The phase voltage referred to is the line voltage referenced to N/L2 input potential.

The parameters below are directly derived from measurements for each phase

Accuracy (20 to 25°C)	
Line frequency (F):	$\pm 0.02\text{Hz}$
Line RMS voltage (Vline):	$\pm 1\%$ of Nominal Vline.
Load RMS voltage (V):	$\pm 1\%$ of Nominal V for voltage readings $> 1\%$ of Nominal V. Unspecified for readings lower than $1\%V_{\text{nom}}$.
Load current (I_{RMS}):	$\pm 1\%$ of Nominal I_{RMS} for current readings $> 3.3\%$ of Nominal I_{RMS} . Unspecified for readings $\leq 3.3\%$ of Nominal I_{RMS}
Load RMS voltage squared (V_{sq}):	$\pm 2\%$ of $(\text{Nominal } V)^2$
Thyristor RMS current squared (I_{sq}):	$\pm 2\%$ of $(\text{Nominal } I)^2$
True load power (P):	$\pm 2\%$ of $(\text{Nominal } V) \times (\text{Nominal } I)$
Frequency resolution	0.1 Hz
Measurement resolution	11 bits of Nominal value (noise free)
Measurement drift with ambient temp.	$< 0.02\%$ of reading / °C

Further parameters (S, PF, Z, IsqBurst, Vsq Burst, and PBurst) are derived from the above, for the network (if relevant). See [section 6.17.1](#) (Network Meas submenu) for further details.

COMMUNICATIONS

Connection	Dual port Ethernet - RJ45
Cable type	Shielded RJ45 CAT5+
Protocol	Modbus TCP
Baud rate	10/100 full or half duplex
Indicators	Tx activity (green) and communications activity (yellow)

This page is deliberately left blank

INDEX

Numerics

10_x 63

A

AbsDif 62

Access

Codes 33

Menu 30

To menus 31

To wiring 10, 11

Acknowledge alarms 42

Add 62

Adding parameters to the Watch list 93

AI Main 51

AI_Fct 70

AI_Type 70

AlarmAck 46

Alarms

Acknowledgement 42

Global 46

Configuration 34

Days / Time 57

Indication 98

Overview 96

Process 96

Status 46

System 96

Which alarms operate relay? 28

Alarms menu 31

Align Tops/Lefts 85

Alm parameters (AI) 51

Alm Relay menu 28

AlmAck (Network) 69

AlmDet

Control 41

Network 69

AlmDis

Control 40

Network 69

AlmLat

Control 42

Network 69

AlmSig

Control 41

Network 69

AlmStop

Control 43

Network 69

Analn Function/Type 18

Ana_In Over C 16

Ana_in type 25

Analogue input

Configuration 51

Specification 109

Wiring 13

Ancillary supply failure 12

AND 58, 60

Any Alarm 46

AnySysAlm 46

Arrow icons 15

Associated documents i

Autoscale 44

B

Back to 90

Black wiring editor items 85

Bleed Scale 38

Block execution order 79

Blue

Arrow

Down 94

Parameters 89

Wiring editor items 85

Bring To Front

Function block context menu 81

Monitor context menu 84

Wire context menu 83

Bulkhead mounting 3, 4

Burst

Fixed 19

Variable 20

C

Cable cross section 9

Capture current values into a data set 94

cDefault Gateway 35

Centre 85

Chain icon 84

Chop Off 22

Chop Off alarm 96

ChopOff 16

ChopOff1Threshold 67

Cleaning 99

Clear memory 33

Clear the selected data set 94

Click to Select Output 80, 82

Clip Bad (Good) 63

Closed Loop

Alarm Acknowledge 42

Alarm detection 41

Alarm disable 40

Alarm Latch 42

Alarm Signalling 41

Alarm Stop 43

ClosedLp 16

Colours

Function blocks etc 85

Software wiring 83

Column enable/disable 89, 90

Comments 83

Context Menu 83

Comms

Address 35

Configuration 35

Gateway tool 91

Menu 24

Pinouts 13

Communications

Specification 111

Component Selection 79

Compounds 86

Conf

Entry/Exit 16

Config		Function block context menu	85
Access code	30	Graphic	85
Menu	25	Graphical Wiring Editor	79
Configuration	32	Monitor	84
Alarm	34	Parameter	90
Analogue input	51	Wire context menu	82
Communications	35	Wiring editor items	85
Control	37	Create	
Diagnostics	40	Compound	79, 85, 86
Limit	39	New empty data set	94
Main	39	New watch/recipe list	94
Setup	38	cSubnetMask	35
Default access code	30	Custom Alarm	46
Digital inputs	52	Cut	
Energy	44	Comment	83
Fault detection	46	Function block context menu	81
Firing output	48	Graphical Wiring Editor	79
Instrument	54	Monitor	84
Config	55	Wire context menu	82
Display	55	Wiring editor items	85
Options	56	Cycle Time	64
IO	50	D	
Analogue input	51	Dashed lines	87
Digital input	52	Data set creation	93
Relay	53	Days above	57
IP Mon	57	Default	
Lgc2	58	Access codes	30
Lgc8	60	Gateway	35
Maths2	62	Delayed Trigger	48
Menu	25	Delete	
Modulator	64	Comment	82
Network	65	Function block context menu	81
Passcode	33	Monitor	84
Relay status	53	Wire	82
Setpoint provider	71	Wiring editor items	85
User Value	72	Dev Name	55
Context Menu		DI1/DI2 Fct	18
Function block	80	DI1_Fct, DI2_Fct	70
Wire	82	Digital I/O	
Control	18, 70	Specification	110
Alarm		Digital input configuration	52
Stop	43	Digital input wiring	13
Alarms		Direct Connection (iTools)	76
Detection	41	Display	14
Disable	40	Language	55
Latch	42	DisRamp	71
Signalling	41	Div	62
Diagnostic menu	40	Down arrow icon	15
Limit		Down arrow key	15
Configuration	39	Download	
Main		The selected data set to the device	94
Configuration	39	Wiring to instrument	79, 84
Menu		Downscale Bad	63
AlmAck	42	Duty cycle	
AlmDet	41	Limiting	22
AlmDis	40	E	
AlmLat	42	Earth connection	5, 6, 7, 8, 10, 11
AlmSig	41	Edit	
Overview	37	Comment	83
Setup menu	38	Parameter Value	81
Copy		Electrical installation	
Comment	83	Supply voltage	9
Diagram fragment	79		
Fragment to file	85		

En Limit	38	Global	
En Timeout	36	Ack	16
Enable		Disable	46
Firing	48	Go Up/Down a Level	90
Input	12	Goto	33
Transfer	38	Graphical Wiring Editor	78
Energy		Greater	
Configuration	44	Equal	58
Counter Resolution	45	Than	58
Engineer		Green tick	15
Access code	30	Greyed-out wiring editor items	87
Passcode	33	Grid on/off	79
EngWorkingSP	71	H	
Enter key	15	Half cycle mode	20
EPack		Heater	18, 70
Panel installation	3	Type	68
Unpacking	3	HeatsinkPreTemp	68
Equal	58	Hidden parameters	89
Exp	63	Hide	
F		Unwired Connections	81
Fall		High/Low Limit	
Bad (Good)	63	Math2	63
Type	58	User value	72
Fallback	63	HiRange	71
1(2)	36	HMI	14
Value		Hold	
Maths2	63	Energy counter	44
FalseGood/FalseBad	58	Host name	35
Fault detection	46	HotSwap	62
Feedback mode	21	HSink Temp	66
FF Type/Gain/Offset	38	Hysteresis	59
FFOnly	38	I	
Find		I	66
End	82	I Nominal	18, 25
Start	82	I2_Transfer	70
Finish	18, 70	I2Transfer	18
Firing		I_Limit	70
Angle limiting	22	ILimit	18
Mode	18, 19, 48	IMaximum	67
Output	48	In	
Firing Mode	25	Firing Output	48
Firmware upgrade	103	Input monitor	57
Flatten compound	79, 86	Invert	60
Force Exec Break	82	Modulator	64
Forward to (blue arrow)	90	In1	
Freq		Lgc8	60
DriftThold	67	Maths	63
Fault	96	In1(2)	
Freq Fault	12	Lgc2	58
Frequency	66	Mul	63
Function Block	80	Indication Alarms	98
Context menu	80	Info menu	29
View	80	I_Nominal	70
Fuse		INominal	67
Dimensions	101	Input	
Driver Module	9	Definition	91
FuseBlown	16	Energy counter	44
Fuses	100	Insert item ahead of selected item	
G		Watch/Recipe	94
General		Instrument	
Ack	46	Config parameters	55
Ghosted wiring editor items	87	Configuration	54

Display configuration	55	Max.	57
Options configuration	56	Meas menu	26
Upgrade	103	MeasVal	
Invert	52, 58	Analogue input	51
IO		Digital I/O	52
Configuration	50	Relay	53
Gateway	36	Menu icon	15
IP	35	Min	57
Address	18, 35	Min On Time	64
Mode	18, 35	Minimum off time	64
Status	35	Minus icon	15
IP Monitor Configuration	57	Missing mains	12
Isq	66	Alarm	96
Burst	66	MissMains	16, 96
iTools	73	Mode	
Connection	73	Firing OP	48
upgrade	103	Modulator	64
L		Modulator	
Label 0(1)	55	Configuration	64
Language	18, 55	Parameters	64
LATCH	58	Monitor	84
Left arrow		Mouse	
Icon	15	Pan	79
Pushbutton	15	Select	79
Less		Move selected item (Watch/Recipe)	94
Equal	58	Mul	62
Than	58	N	
Lgc2 Configuration	58	Net Type	55
LGC8 Configuration	60	NetProc alarm	46
Limit	71	NetwDip	16
Act	16	Network	
Enable	38	Alarm	
Limitation		Acknowledge menu	69
Active	98	Detect menu	69
Alarm Acknowledge	42	Disable menu	69
Alarm Detection	41	Latch menu	69
Alarm Disable	40	Signal menu	69
Alarm Latch	42	Signalling menu	69
Alarm Signalling	41	Stop firing menu	69
Alarm Stop	43	Configuration	65
Link Speed	18, 36	Dips	96
Ln	63	Menu	
Load		Setup	67
Over-Current	98	Type	67
Overl.	16	Network dips	12
Type	48	Nominal PV	38
Local/remote setpoint selection	15	Not Equal	58
LocalSP	71	Number of inputs	60
Log	62	NumberChopOff	67
Logic		O	
Firing mode	19	Off	58
Mode	64	OPC	94
Low Limit	63	Open an existing watch/recipe file	94
M		Oper	58
MAC12 (34) (56)	36	Operation	
Magenta wiring editor items	85	Lgc8	60
Mains		Operator	
Frequency fault alarm	96	Access code	30
Network measurements	111	Interface	14
MainsFreq	16	Menu	23
Maintenance	99	OR	58, 60
Math2 Configuration Menu	62	Out	
		Invert	60

Lgc8	60	PV	
Math2	63	Analogue input	51
Modulator	64	Digital I/O	52
Output	58	Relay source	53
Over Temperature	96	PV Transfer	
Over Volt	16	Alarm Acknowledge	42
OverThreshold	68, 98	Alarm Detection	41
OverVoltage Alarm	97	Alarm Disable	40
OverVoltThreshold	67, 97	Alarm Latch	42
P		Alarm Signalling	41
P	66	Alarm Stop	43
PA Limit	48	Q	
Pan tool	79	QS Entry/Exit	16
Param0(1)MB	55	Quickcode	
Parameter		Access code	30
Addresses	95	Menu	17
Blue	89	QuickCodePasscode	33
Explorer	88	R	
Help	81, 84, 90	R/L	15
Properties	81, 90	Ramp	
Partial Load Failure (PLF)		Rate	71
Alarm	97	Status	48
Passcode	33	RangeHigh	
Passcode1/2/3	56	Analogue input	51
Passcodes	29	RangeLow	
Paste		Analogue input	51
Comment	83	RateDone	71
Diagram fragment	79	Red cross icon	15
Error	81	Red wiring editor items	85
Fragment From File	85	Redo	79
Function block context menu	81	Refresh	70
Graphical Wiring Editor	79	Relay	
Monitor	84	Selecting alarms to operate	28
Wire context menu	82	Specification	110
Wiring editor items	85	Status	53
PBurst	66	Wiring	13
PF	66	Remote	
Phase angle		1 (2)	71
Control	20	Remote/Local setpoint selection	15
Reduction burst firing	39	Remove	
Pinout for relay	12	Recipe parameter	94
PLF	16	RemSelect	71
Adjusted	68	Rename Wiring Editor diagram	85
AdjustReq	68	Re-Route	
Sensitivity	68	Wire	80, 82
PLF Adjust R	25	Wires	85
PLF Adjusted	25	Reset	
Plus and minus icons	15	Energy counter	44
Power		IP Monitor	57
Math2 operation	62	Resolution	
Type	55	Math2	63
PrcValTfr	16	User value	72
Pref Master	35	Return key	15
Preventive Maintenance	99	Right/Left arrow icons	15
Process Alarms	96	S	
Process Value Transfer active	98	S	66
Protocol	36	Safety earth	9
Push pin	90	Connection	5, 6, 7, 8, 10, 11
Push to Back	84	Safety notes	1
Function block context menu	81	Safety Ramp	48
Wire context menu	83	Status	48
Pushbuttons	15	Save Graphic	85

Save the current watch/recipe list	94	T	
Scaling Factor	56	Tags	80, 82
Scan	77	Target setpoint scaling	71
Scan all device addresses	77	Thick wires	83
Scroll keys	15	Threshold	57
Sel1	63	Thyr SC	16, 96
Select	63	Thyristor	
All	85	Enable	9
Language	55	Heatsink temperature	96
Select which alarms are to operate the relay	28	Open circuit	96
Selecting components	79	Short circuit	96
SelMax/Min	62	Short/open circuit	12
Serial No	55	Thyristor protection fuses	100
Serial number	29	Tightening torque	3, 4, 9
SerialNo	56	Time Above	57
Setprov configuration	71	Timeout	36
Setup		Enable	36
Network	67	Timer Res	55
Show names	84	TLF	16, 96
Show Wires Using Tags	80	Total Load Failure (TLF) alarm	96
Show/Hide grid	79	Transfer	
Signal wiring	12	Enable	38
SmpHld	62	Mode	21
Snapshot	93	Transfo	18
Soft Start/Stop	25, 48	Trim	38
Softkey icons	15	TrueGood/TrueBad	58
Software	55	Type	
Effectivity	i	Analogue input	51
Upgrade	104	Digital I/O	52
Software version	56	U	
Space Evenly	85	Undelete	
Specification	107	Comment	82
Analogue input	109	Function block context menu	81
Communications	111	Monitor	84
Digital inputs	110	Wire	83
EMC	108	Wiring editor items	85
Environment	107	Under Volt	16
Input/output modules		UnderVoltage Alarm	97
Standard	109	UnderVoltThreshold	67
Operator interface	109	Undo	79
Physical	107	Units	
Power requirements	107	Math2	63
Relay	110	User value	72
SPSelect	71	Unlink	
SPTTrack	71	Comment	83
SPUnits	71	Monitor	84
Sqrt	62	Up arrow key	15
SRV name	35	Up/down arrow icons	15
Standby	38	UPGPass	33
Status		Upgrading	
IPMon	57	Firmware	103
Lgc2	59	Instrument	103
Maths	63	iTools	103
User value	72	Software	104
Strat menu	27	Upscale Bad	63
StratStatus	46	Use Tags	82
Sub	62	User Value	
SubNet Mask	18, 35	Configuration	72
Supply frequency fault	12	UsrEnerg	44
SW version	29	UsrUnit	44
Switch PA	64	V	
System alarms	96	V	66

V Nominal	18
Value	
User	72
Vdips	96
Threshold	12, 67, 96
Vline	66
VLine Nominal	25
Vline Nominal	67
VLoadType	67
VMaximum	67
V_Nominal	70
Vsq	66
VsqBurst	66

W

Watch/Recipe editor	93
Adding parameters	93
Capture current values into a data set	94
Clear the selected data set	94
Create a new empty data set	94
Create a new watch/recipe list	94
Data set creation	93
Download the selected data set to the device	94
Insert item ahead of selected item	94
Move selected item	94
Open an existing watch/recipe file	94
Open OPC Scope	94
Remove recipe parameter	94
Save the current watch/recipe list	94
Snapshot	94

Wiring

Mains	9
Software	82
Colours	83
Context Menu	82
Thick wires	83

WorkingSP	71
-----------------	----

X

XFmr.	70
XFRMR	18
XOR	58, 60

Z

Z	66
Zoom	79
Zref	68

This page is deliberately left blank

Eurotherm: International sales and support www.eurotherm.com

Contact Information

Eurotherm Head Office
Faraday Close,
Durrington,
Worthing, West Sussex,
BN13 3PL

Sales Enquiries
T +44 (0)1903 695888
F 0845 130 9936

General Enquiries
T +44 (0)1903 268500
F 0845 265982

Worldwide Offices
www.eurotherm.com/global



Scan for local contacts

Represented by:

©Copyright Invensys Eurotherm Limited 2014

Invensys, Eurotherm, the Eurotherm logo, Chessell, EurothermSuite, Mini8, Eycon, Eyris, EPower, EPack nanodac, piccolo, versadac, optivis, Foxboro, and Wonderware are trademarks of Invensys plc, its subsidiaries and affiliates. All other brands may be trademarks of their respective owners.

All rights are strictly reserved. No part of this document may be reproduced, modified or transmitted in any form by any means, neither may it be stored in a retrieval system other than for the purpose to act as an aid in operating the equipment to which the document relates, without the prior written permission of Invensys Eurotherm Limited.

Eurotherm Limited pursues a policy of continuous development and product improvement. The specifications in this document may therefore be changed without notice. The information in this document is given in good faith, but is intended for guidance only. Eurotherm Limited will accept no responsibility for any losses arising from errors in this document.